

Original Manual

# Protection System E16x456

with  
Overspeed Protection  
and  
Voters for external Trip Conditions

Conformal with  
IEC61508; SIL2  
API670




Figure 1: E16x456 System Front View

## Table of Contents

Content	Page
<b>Table of Contents</b> .....	<b>2</b>
<b>1 General Informations</b> .....	<b>5</b>
1.1 List of Figures.....	5
1.2 List of Abbreviations .....	6
1.3 System Applications and Explanation.....	8
1.4 Key Features of System E16x456 .....	9
1.5 Ordering Key for Systems E16x456.abc .....	10
1.6 Certifications.....	11
1.6.1 Certification IEC61508; SIL2 .....	11
1.6.2 This chapter is left blank intentionally .....	11
1.6.3 This chapter is left blank intentionally .....	12
1.7 Safety Data.....	13
1.7.1 Safety Data IEC61508; SIL2.....	13
1.7.2 This Chapter is left blank intentionally .....	13
1.8 External Tests .....	13
1.8.1 External tests during normal operation by PLC or operator .....	13
1.8.2 Test of 2oo3 solenoid valve block .....	13
<b>2 System Structure and I/Os</b> .....	<b>14</b>
2.1 System Structure.....	14
2.1.1 Speed Sensors .....	14
2.1.2 System Components .....	14
2.1.3 System Design .....	14
2.1.4 System Structure Diagrams .....	15
2.1.5 System Wiring Diagrams .....	17
2.1.6 Connection of Sensors to the Speed Signal Inputs.....	19
2.2 Inputs of the System.....	20
2.2.1 Speed Signal .....	20
2.2.2 Rotation Direction Signal (F/R : Forward/Reverse).....	20
2.2.3 Reset of Alarms .....	20
2.2.4 Test Lock .....	20
2.2.5 Start Auto Test Sequence .....	21
2.2.6 Test I, Test II, Test III .....	22
2.2.7 Starter (Override of SP2) .....	22
2.2.8 SP1B Valid.....	22
2.2.9 Feedback inputs of the 2oo3 solenoid valve block .....	22
2.2.10 External Signals for Voter 1 .....	22
2.2.11 External Signals for Voters 2 ... 6.....	22
2.3 Outputs of the System .....	23
2.3.1 System Warning Alarm 1 and System Warning Alarm 2 .....	23
2.3.2 Speed Signal Repeater.....	23
2.3.3 Monitor Warning Alarm .....	23
2.3.4 Speed Alarm SP3 .....	24
2.3.5 Analog Outputs proportional to measured speed (Option).....	24
2.3.6 Rotation Direction Detection .....	24
2.3.7 Speed Trip Logic Output (2oo3 voted) .....	24
2.3.8 Trip Lines IV, V, VI .....	24
2.3.9 Trip Lines I, II, III .....	24
2.3.10 Logic Outputs LO1 through LO6 (voted 2oo3).....	24

2.4	Power Supply .....	25
2.5	Data Interface .....	25
2.5.1	PROFIBUS Interface for Status and Diagnostics of the System .....	25
2.5.2	RS232 Interface with Interface Software IS-RS232-E16 (for OEM only) .....	25
2.5.3	RS232 Interface with Interface Software IS-RS232-E16-L2 (for End User) .....	25
<b>3</b>	<b>Technical Specifications.....</b>	<b>26</b>
3.1	Technical Data of Inputs .....	26
3.1.1	Technical Data of Speed Signal Inputs .....	26
3.1.1.1	Hall Sensor Inputs .....	26
3.1.1.2	Eddy Current Sensor Inputs or MPU Inputs .....	26
3.1.2	Technical Data of Direction Inputs .....	26
3.1.3	Technical Data of Binary Inputs (excluding Voter 1).....	26
3.1.4	Technical Data of Binary Inputs of Voter 1 .....	26
3.2	Technical Data of Outputs .....	27
3.2.1	Technical Data of Speed Sensor Signal Repeater Outputs.....	27
3.2.2	Technical Data of Analog Outputs.....	27
3.2.3	Technical Data of Opto Relay Outputs.....	27
3.2.4	Technical Data of Logic Outputs .....	27
3.2.5	Technical Data of Trip Lines IV, V, VI .....	28
3.2.6	Technical Data of Trip Lines I, II, III.....	28
3.3	Technical Data of Power Supply .....	29
3.4	Installation Conditions .....	29
3.5	Protection Grade .....	29
3.6	Connectors .....	29
3.7	Conformity to Standards.....	29
3.8	Dimensions of one rack of System E16A456 .....	30
3.9	Dimensions of system E16E456.....	31
3.10	Dimensions and Features of E16G456 Enclosure.....	32
3.11	Weight of E16x456 .....	32
<b>4</b>	<b>Safety Notes for Installation and Operation.....</b>	<b>33</b>
4.1	Safety Notes for Installation.....	33
4.1.1	General Instructions.....	33
4.1.2	EMI .....	33
4.2	Safety Notes for Operation .....	33
4.2.1	Safety Notes on Commissioning.....	33
<b>5</b>	<b>Description of Monitor E1666.....</b>	<b>34</b>
5.1	Display and Frontside Operational Elements .....	34
5.1.1	Front View of Monitor E1666 .....	34
5.1.2	Status-LEDs.....	34
5.1.3	Display during Test Procedures .....	34
5.1.4	Values accessible during normal operation .....	35
5.1.5	Display of Firmware release state and CRC-Parameter-Checksum of Monitor .....	35
5.1.6	Special Display Mode 1 .....	36
5.1.7	Special Display Mode 2 .....	36
5.1.8	Frontside Reset of Alarms and Event codes .....	36
5.1.9	Data Interface .....	36
5.2	Functions of Monitor E1666.....	37
5.2.1	Speed Measurement .....	37
5.2.2	Functions for Overspeed Protection .....	37
5.2.3	Functions for External Trip by Voters .....	37
5.2.4	Permanent Monitoring Functions.....	37

5.2.5	Functional Tests.....	37
5.2.6	Selftest of Monitor.....	37
<b>6</b>	<b>Description of Testgenerator E1698 .....</b>	<b>39</b>
6.1	Display and Frontside Operational Elements .....	39
6.1.1	Front View of Testgenerator E1698 .....	39
6.1.2	Status-LEDs.....	39
6.1.3	Display during Test Procedures .....	40
6.1.4	Values accessible during normal operation .....	40
6.1.5	Display of Firmware release state and CRC-Parameter-Checksum of Monitor .....	40
6.1.6	Frontside Reset of Alarms and Event codes .....	40
6.1.7	Manual Start of a Monitor-Test Sequence.....	40
6.1.8	Manual Start of a Trip-Line-Test Sequence.....	40
6.1.9	Data Interface .....	40
6.2	Functions of Testgenerator 1698 .....	41
6.2.1	Permanent Monitoring of Feedbacks .....	41
6.2.2	Monitor-Test Sequence.....	41
6.2.3	Trip-Line-Test Sequence (Test of 2003 Solenoid Valve Block).....	42
6.2.4	Cross-check between CPUs of Test-Generator .....	42
6.2.5	Selftest of CPUs .....	42
<b>7</b>	<b>Programming of the Modules.....</b>	<b>43</b>
7.1	Programming of the Modules via Front Keyboard .....	43
7.2	Programming of the Modules via RS232-Interface.....	44
7.3	Default Values .....	44
<b>8</b>	<b>Parameters of Monitor E1666.....</b>	<b>45</b>
8.1	Summary of parameters and their default values .....	45
8.2	Description of Parameters and their Settings of Monitor E1666 .....	49
<b>9</b>	<b>Parameters of Test-Generator E1698 .....</b>	<b>77</b>
9.1	Summary of parameters and their default values .....	77
9.2	Description of Parameters and their Settings of Test-Generator E1698 .....	78
<b>10</b>	<b>Event codes and Troubleshooting.....</b>	<b>85</b>
10.1	Event codes on display of Monitor E1666 .....	85
10.2	Troubleshooting if display of Monitor reads E.0.4.0.0 .....	86
10.3	Event codes on display of Testgenerator E1698 .....	87
	Event codes on display of E1698 (continued) .....	88
<b>11</b>	<b>Revision Notes .....</b>	<b>89</b>

# 1 General Informations

## 1.1 List of Figures

Figure 1:	E16x456 System Front View.....	1
Figure 2:	E16x456 System Structure Diagram 1 of 2 : Testgenerator and speed section of Monitors .....	15
Figure 3:	E16x456 System Structure Diagram 2 of 2 : Voter section of Monitors .....	16
Figure 4:	E16x456 System Wiring Diagram 1 of 3 : Testgenerator and speed section of Monitors.....	17
Figure 5:	E16x456 System Wiring Diagram 2 of 3 : Voter section of Monitors.....	18
Figure 6:	E16x456 System Wiring Diagram 3 of 3 : Connection of speed sensors.....	19
Figure 7:	Dimensions of System E16A456 .....	30
Figure 8:	Dimensions of System E16E456 .....	31
Figure 9:	Dimensions of E16G456 Enclosure.....	32
Figure 10:	Front View of Monitor E1666 .....	34
Figure 11:	Front View of Testgenerator E1698 .....	39
Figure 12:	SP1 as a variable of the acceleration .....	57

## 1.2 List of Abbreviations

Abbreviation	Meaning
altern.	alternative
API	Technical standards of the "American Petroleum Institute"
A5S	BRAUN GmbH Sensor series
AWG/kcmil	Code number according to the "American Wire Gauge" System
approx.	approximately
CH1	Channel 1
CH2	Channel 2
CH3	Channel 3
CCF	Common Cause Failure
CPU	Central Processing Unit
DCavg	Diagnostic Coverage average
DCS	Distributed Control System
DIN	Deutsches Institut für Normung (German Institute for Standardization)
dn/dt	Change of speed per time unit (Acceleration)
EEPROM	Electrically Erasable Programmable Read Only Memory
EMV	Electro magnetic compatibility
EN	European Norm
F/R	Forward/Reverse (Forward/Backward)
HE	Height units
HFT	Hardware Fault Tolerance
IEC	International Electrotechnical Commission
incl.	inclusive
IPxx	Ingress Protection Number xx according to DIN EN 60529
ISO	International Organization for Standardization
LED	Light Emitting Diode
LOx	Logic Output x
max.	maximum
min.	minimum
MPU	Magnetic Pick Up
MTTFd	Mean Time To dangerous Fault
MTTR	Mean Time to Restoration
Moo3	Median out of 3 selection logic
n	Short term for Speed
NEMAx	National Electrical Manufacturers Association Number x
PFDavg	Probability of Fault on Demand average
PELV	Protective Extra Low Voltage
PLC	Programmable Logic Controller
RAM	Random Access Memory
RPM	Revolutions Per Minute
sec	second
SELV	Safety Extra Low Voltage
SFF	Safe Failure Fraction
SILx	Safety Integrity Level x
SPx	SetPoint x
SPVx	SetPoint Voter x
SP1var	SetPoint 1 variable
	continued on next page

Abbreviation	Meaning
TE	Width unit
TMR	Triple Modular Redundant
Tproof	Proof Test Interval
UL/cUL	Acc. US Underwriter Laboratories or Canadian Underwriter Laboratories standards
VCC	Valve Control Circuit
VCM	Valve Control Module
Vdc	Volt direct current
Vpp	Volt peak-to-peak
1oo2	1 out of 2 voting logic
1oo3	1 out of 3 voting logic
2oo2	2 out of 2 voting logic
2oo3	2 out of 3 voting logic

Protection of rotating machinery such as turbines, expanders, compressors and motors with safety requirements SIL2/IEC61508 and/or API 670 versus Overspeed and other Critical Conditions.

The E16x456 protection system incorporates one testgenerator of type E1698 and three modules of type E1666 for evaluation of speed signals and external trip signals. These modules are named "Monitors".

The logic blocks of the Monitors for the evaluation of the external trip signals are named "Voter". Each of the monitors represents a "Channel" (A, B and C) for processing of the speed signals and external trip signals.

The logic results of the three Channels are connected internally via the trip relays to form six 2oo3 trip circuits, whereof the circuits I, II and III are referred to as "Trip Lines". The three Trip Lines of the E16x456 system are used to switch-off of valves or other drives respective to actuate a "2oo3 solenoid valve block".

The trip state of the E16x456 system may be locked. This function is referred to as "Trip Lock"

Trip is initiated if:

- 2oo3 Monitors detect overspeed condition
- 2oo3 speed sensors are detected as faulty by Monitors
- 2oo3 Monitors detect external trip condition via Voters (1oo2, 2oo2, 2oo3 or 3oo3 selectable)



## 1.4 Key Features of System E16x456

Trip initiation function is SIL2/IEC61508 and DIN EN ISO 13849:2008 Cat.3 PLe compliant as stand alone unit (without external testing by PLC or by DCS or by operator).

Total response time from trip event to de-energize the Trip Lines:  
less than 15 milliseconds.

Test Interval = 20 Years (no periodic maintenance required).

**Maximum safety at maximum availability by:**

- TMR (Triple Modular Redundancy) with three Monitors E1666
- Triple speed measurement and evaluation by each Monitor
- Variable overspeed alarm depending on acceleration
- Monitoring versus speed low limit to protect against incorrect mounting or malfunction of speed sensors
- Permanent monitoring of speed sensors
- Evaluation of external trip-condition signals by Voters in each Monitor. Response to signals selectable for each Voter individually (logic function, low/high: trip, response time)
- Monitoring of Monitors by Testgenerator
- Permanent monitoring of feedback signals from a 2oo3 solenoid valve block by the test generator with cyclical, fully automatic or externally controllable tests
- Permanent monitoring of the status of the trip lines by the test generator and cyclical, fully automatic testing of the reaction to triggering of the trip lines using feedback signals from a 2oo3 solenoid valve block. This block can also be manually excited via the keyboard located on the front of the test generator or with an external signal
- Each Trip Line (trip circuit) in 2oo3 technique
- Trip Lines I, II, III, IV, V, VI are formed by safety relays with force guided contact sets
- Trip Line monitoring with Trip Lock function (selectable)

**Additional features of the E16x456 system:**

- Overlapping tests by DCS are possible
- Display in each module for measured values and diagnostics
- Alarm outputs via opto relays or PROFIBUS to DCS
- Free extra alarm from each Monitor
- Up to 6 speed setpoints with 2oo3 logic outputs (if Voters are not required)
- Sensor signal repeater outputs, free floating and push/pull
- Optional analog output (to represent the speed) 0/4..20 mA for each Monitor
- Rotation direction alarm (only with sensors type A5S with rotating direction output)
- Parameters may be set by front keys (protected by code digit) or by RS232 interface (password protected)
- Two PROFIBUS interfaces to DCS

## 1.5 Ordering Key for Systems E16x456.abc

E16x456.abc

- c = 1** : Speed Signal Inputs and power supply for A5S sensors
- c = 2** : Speed Signal Inputs and power supply for Eddy Current Sensors
- c = 3** : Speed Signal Inputs for MPU (magnetic pick up)

- b = 1** : 1 Voter in each Monitor for external trip release condition
- b = 2** : 6 Voters in each Monitor for external trip release conditions

- a = 0** : without Analog Output (to represent the speed)
- a = 1** : 1 Analog Output in each Monitor A, B, C
- a = 2** : 1 Analog Output rated SIL2 in each Monitor A, B, C

- x = A** : Surface Mount Version
- x = E** : 19-Inch Rack File
- x = G** : Nema 4 Version with front window (surface mount)

Example:

- E16A456.021 : Surface Mount Version, without Analog Output, with 6 Voters, Speed Signal Inputs for A5S sensors
- E16A456.112 : Surface Mount Version, with Analog Output, with 1 Voter, Speed Signal Inputs for eddy current sensors
- E16A456.013 : Surface Mount Version, with 1 Voter, Speed Signal Inputs for MPU

## **1.6 Certifications**

### **1.6.1 Certification IEC61508; SIL2**

The E16x456 system is certified by TÜV to be compliant with IEC61508; SIL2 as a stand alone TMR Trip-System for the functions:

- Overspeed Protection
- Voters for external Trip Release Conditions, such as emergency stop, boiler protection etc.
- Analog Output (for actual speed value)
- 2oo3 Trip Outputs

### **1.6.2 This chapter is left blank intentionally**

**1.6.3 This chapter is left blank intentionally**

## **1.7 Safety Data**

### **1.7.1 Safety Data IEC61508; SIL2**

System type B; HFT = 1; Architecture 2oo3, Service Time 20 years  
**PFDavg** =  $1,81 \cdot 10^{-4}$  at **T1** (Proof Check Interval) = 20 years

### **1.7.2 This Chapter is left blank intentionally**

## **1.8 External Tests**

### **1.8.1 External tests during normal operation by PLC or operator**

The trip release ability of a 2oo3 solenoid valve block can be verified by external tests as described in 1.6.1.

Test interval for test 1.6.1 according recommendations of the 2oo3 solenoid valve block supplier.

### **1.8.2 Test of 2oo3 solenoid valve block**

Test can only be performed if the Monitors are not in trip status.

The test is performed for each trip-line separately by control signals Test of Trip-Line I, II, III. The response of the 2oo3 solenoid valve block must be checked by the PLC resp. the operator.

Note:

Test of two or three trip-lines at the same time will release trip of the machine.

## 2 System Structure and I/Os

### 2.1 System Structure

The structure of the system is shown in chapter **2.1.4** (figures 2 and 3).

The wiring of the system is shown in chapter **2.1.5** (figures 4,5 and 6).

The indexes "see 2.x.x" in these figures refer to the corresponding chapters 2.x.x. which describe the according functions.

#### 2.1.1 Speed Sensors

With versions E16x456.xx1:

Three A5S differential Hall effect sensors, with integrated signal amplifier are placed at the machine shaft.

The differential Hall effect sensors A5S are not susceptible to uniform external magnetic fields. Air gap variations between machine and sensor do not create false signals.

With versions E16x456.xx2:

Three Speed signals from Eddy Current Sensors are evaluated.

With versions E16x456.xx3:

Three Speed signals from MPU Sensors are evaluated.

#### 2.1.2 System Components

The system comprises one Testgenerator E1698 and three Monitors E1666.

The Testgenerator E1698 checks and validates the performance of the Monitors, of the Trip Lines and of an external 2oo3 solenoid valve block by tests.

The Monitors E1666 monitor the sensors, the speed and the external trip conditions.

Trip is initiated by de-energizing of the Trip Lines if:

- 2oo3 Monitors detect overspeed condition
- 2oo3 speed sensors are detected as faulty by Monitors
- 2oo3 Monitors detect external trip condition via Voters (1oo2, 2oo2, 2oo3 or 3oo3 selectable)

The Monitors and the Testgenerator are interconnected via the rack backplane. The rack backplane does not contain any active components.

#### 2.1.3 System Design

The system is available as

- 19-Inch Rack File, 3HE 84TE (E16E456) or
- for surface mounting (E16A456) or
- as NEMA4 version (E16G456).

## 2.1.4 System Structure Diagrams




Figure 2: E16x456 System Structure Diagram 1 of 2 : Testgenerator and speed section of Monitors




Figure 3: E16x456 System Structure Diagram 2 of 2 : Voter section of Monitors



## 2.1.5 System Wiring Diagrams




Figure 4: E16x456 System Wiring Diagram 1 of 3 : Testgenerator and speed section of Monitors





Figure 5: E16x456 System Wiring Diagram 2 of 3 : Voter section of Monitors

## 2.1.6 Connection of Sensors to the Speed Signal Inputs



Rev. 00 / 02.2012

Figure 6: E16x456 System Wiring Diagram 3 of 3 : Connection of speed sensors

## **2.2 Inputs of the System**

### **2.2.1 Speed Signal**

The speed signals are internally wired to all three Monitors in parallel.

With versions E16x456.xx1:

The speed signal inputs match the values of sensors A5S...

The speed signal inputs are rated SIL2/IEC61508 if sensors of type A5S. (also via barriers D461) are connected. For other sensors this is only valid, if the sensor supplier guarantees, that the sensors will not give erratic speed signals due to a common cause failure. The instructions of the sensor supplier must be observed.

Technical Data of inputs see 3.1.1.1.

With versions E16x456.xx2:

The signal inputs match the values of eddy current sensors.

The speed signal inputs are rated SIL2/IEC61508, if the sensor supplier guarantees, that the sensors will not give erratic speed signals due to a common cause failure. The instructions of the sensor supplier must be observed.

Technical Data of inputs see 3.1.1.2.

With versions E16x456.xx3:

The signal inputs match the values of MPUs.

The speed signal inputs are rated SIL2/IEC61508, if the sensor supplier guarantees, that the sensors will not give erratic speed signals due to a common cause failure. The instructions of the sensor supplier must be observed.

Technical Data of inputs see 3.1.1.2.

### **2.2.2 Rotation Direction Signal (F/R : Forward/Reverse)**

The direction signal inputs match the values of the sensors A5S with direction signal.

The direction signals are internally wired to all three monitors in parallel.

The direction signal inputs are rated SIL2/IEC61508 (valid only for sensors A5S3..).

Technical Data of inputs see 3.1.2.

### **2.2.3 Reset of Alarms**

The Reset signal is internally connected to all modules in parallel. It resets a no longer prevailing, but latched alarm or trip condition.

A signal transition from low to high will reset a latched alarm.

Minimum Time of Reset Signal: > 1 second to ensure correct reset of all modules.

The input "Reset of Alarms" is rated SIL2/IEC61508 provided that the signal source is rated SIL2/IEC61508.

Technical Data of input see 3.1.3.

### **2.2.4 Test Lock**

A high signal will abort any running system inherent cyclic proof test and inhibit further tests as long as the signal is high. If the signal is true for more than 60 minutes, the alarms System Alarm 1 and System Alarm 2 are initiated.

The input Test Lock is rated SIL2/IEC61508 provided that the signal source is rated SIL2/IEC61508.

Technical data of input see 3.1.3.

### 2.2.5

#### Start Auto Test Sequence

A signal transition from low to high will start an automatic test sequence. First the test (if selected, see step P03.01 of E1698) of the Trip Lines for the Valve Control Modules is performed, two minutes later the test of the Monitors is performed.

The input Start Auto Test Sequence is rated SIL2/IEC61508 provided that the signal source is rated SIL2/IEC61508.

Technical data of input see 3.1.3.

### **2.2.6 Test I, Test II, Test III**

The inputs Test I, II, III are enabled, if the Testgenerator E1698 is programmed to external Trip Line Test (see parameter P03.01 of E1698).

If the input is high, the corresponding Trip Line will switch to trip condition.

The inputs may be configured to inhibit simultaneous test of two or three Trip Lines.

The input Test I, II, III are rated SIL2/IEC61508 provided that the signal source is rated SIL2/IEC61508.

Technical data of inputs see 3.1.3.

### **2.2.7 Starter (Override of SP2)**

Each Monitor has one input for the starter condition. As long as the input is high, the starter condition is true.

During starter condition the monitoring versus a speed low limit (SP2) is disabled.

The inputs Starter are rated SIL2/IEC61508 provided that the signal source is rated SIL2/IEC61508.

Technical data of inputs see 3.1.3.

### **2.2.8 SP1B Valid**

Each Monitor has one input to select SP1B as trip setpoint.

As long as the input is high, setpoint value SP1B (see step P03.03 of E1666) is true.

With open input (low), setpoint value SP1A (see P03.00 of E1666) is true.

The inputs SP1B Valid are rated SIL2/IEC61508 provided that the signal source is rated SIL2/IEC61508.

Technical data of inputs see 3.1.3.

### **2.2.9 Feedback inputs of the 2oo3 solenoid valve block**

The feedback inputs are connected on the E1698 test generator.

The inputs are only monitored when the "Automatic trip line test" is activated (see Step P03.01 of E1698).

The active level (High or Low as trip criterion) can be selected in Step P03.03 of E1698.

The "Feedback of 2oo3 solenoid valve block" inputs are SIL2/IEC61508 compliant (under the condition that the signal source is SIL2/IEC61508 compliant).

See 3.1.3 for the technical data of the inputs.

### **2.2.10 External Signals for Voter 1**

The input signals for Voter 1 are internally connected to all Monitors in parallel.

The input load of Voter 1 meets the requirements for the redundant outputs of a failsafe PLC (load > 45 mA per input).

The signal truth level (high or low as trip condition), the voting principle (1oo2, 2oo2, 2oo3, 3oo3) and the response time is selectable. Configuration of the Voter is done in steps P10.xx of E1666.

The inputs Voter 1 are rated SIL2/IEC61508 provided that the signal source is rated SIL2/IEC61508.

Technical data of inputs see 3.1.4.

### **2.2.11 External Signals for Voters 2 ... 6**

The input signals for Voters 2 ... 6 are internally connected to all Monitors in parallel.

The signal truth level (high or low as a trip condition), the voting principle (1oo2, 2oo2, 2oo3, 3oo3) and the response time is selectable for each Voter individually. Configuration of Voters is done in steps P11.xx to P15.xx of E1666.

The inputs Voter 2...6 are rated SIL2/IEC61508 provided that the signal source is rated SIL2/IEC61508.

Technical data of inputs see 3.1.3.

**Note:**

Systems E16x456.x1x do not have inputs for Voters 2... 6.

## 2.3 Outputs of the System

### 2.3.1 System Warning Alarm 1 and System Warning Alarm 2

The alarms System Warning Alarm 1 and System Warning Alarm 2 from Testgenerator E1698 are initiated if at least one of the following conditions is true:

- a Monitor does not show correct response or
- a Monitor issues a Sensor Fault alarm or
- the feedback signals from the Valve Control Modules do not show correct response (if monitored) or
- a Monitor issues Antivalence fault alarm of Voter inputs

**Note:**

If the alarms System Alarm 1 and System Alarm 2 do not have the same status, the Testgenerator E1698 itself has a malfunction.

The outputs System Alarm 1 and System Alarm 2 are rated SIL2/IEC61508.

Technical data of outputs see 3.2.3.

### 2.3.2 Speed Signal Repeater

Each Monitor repeats the speed signal of its main sensor (Monitor A repeats sensor signal A) to the periphery at a non-reactive pulse signal output.

The Speed Signal Repeater Outputs are rated SIL2/IEC61508.

Technical data of outputs see 3.2.1.

### 2.3.3 Monitor Warning Alarm

The Monitor warning alarm (for each Monitor individually) is initiated if at least one of the following conditions is true:

- Monitor initiates trip (due to overspeed or Voter), if selected in step P02.11 of E1666
- Deviation of its own sensors versus both sensors of neighbor Monitors, if monitored selection in steps P02.07 through P02.09 of E1666.
- Measured speed lower than SP2 (after starter condition), if monitored selection in step P02.06 of E1666
- Sensor circuit fault, if monitored selections in steps P02.04 and P02.05 of E1666
- If starter condition is still true and speed exceeds 50% of nominal speed (as set in step P01.03), if selected in step P02.0)

**Note:**

The Monitor Warning Alarm is not initiated, if the Monitor detects antivalence at its Voter inputs. This status is forwarded to the Testgenerator E1698 which then initiates the alarms System Alarm 1 and System Alarm 2. In case of alarm chapter "Troubleshooting " of the manual must be consulted.

The outputs Monitor Warning Alarm are rated SIL2/IEC61508.

Technical data of outputs see 3.2.3.

### 2.3.4 Speed Alarm SP3

Each Monitor has a free adjustable speed alarm output SP3.  
Configuration of SP3 in steps P05.xx of E1666.  
The outputs Speed Alarm SP3 are rated SIL2/IEC61508.  
Technical data of outputs see 3.2.3.

### 2.3.5 Analog Outputs proportional to measured speed (Option)

The (optional) analog outputs have a range of 0/4 .. 20 mA.  
Configuration of the analog output in steps P08.xx of E1666.  
The analog outputs of versions E16x456.1xx and E16x456.2xx are rated SIL2/IEC61508.  
Technical data of outputs see 3.2.2.

### 2.3.6 Rotation Direction Detection

If operated with sensors A5S with rotating direction signal, the sense of direction is signalized.  
Each Monitor votes the rotating direction input signals 2oo3. Each Monitor has a rotating direction detection output.  
The outputs Rotating Direction Detection are rated SIL2/IEC61508.  
Technical data of outputs see 3.2.3.

### 2.3.7 Speed Trip Logic Output (2oo3 voted)

Speed trip logic output is actuated, if minimum 2 of the 3 Monitors detect overspeed condition. If overspeed status is latched, the alarm will persist until reset (see 5.2.2).  
Output high : no overspeed trip  
Output low : overspeed trip  
The Speed Trip Logic Output is rated SIL2/IEC61508.  
Technical data of output see 3.2.4.

### 2.3.8 Trip Lines IV, V, VI

The Trip Lines IV, V, VI are 2oo3 circuits formed by contacts of safety trip relays IV and V of Monitors A, B, C.  
Trip is initiated if minimum two Monitors E1666 are in trip status.  
Trip Lines IV, V, VI are intended to signalize the trip to a DCS or PLC.  
The outputs of Trip Lines IV, V, VI are rated SIL2/IEC61508.  
Technical data of output see 3.2.5.

### 2.3.9 Trip Lines I, II, III

The Trip Lines I, II, III are 2oo3 circuits formed by contacts of safety trip relays I or II or III of Monitors A, B and C.  
Trip is initiated if minimum two Monitors E1666 are in trip status.  
Trip Lines I, II, III are, for example, provided for operating a 2oo3 solenoid valve block.  
The outputs of Trip Lines I, II, III are rated SIL2/IEC61508.  
Technical data of output see 3.2.6.

### 2.3.10 Logic Outputs LO1 through LO6 (voted 2oo3)

The Logic Outputs LO may be assigned to signalize a Voter trip or to a speed alarm.  
If assigned to Voter trip Ausgang High: output high : no trip of Voter  
output low : trip of Voter  
If assigned to speed alarm: output high/low if n > SP is selectable.  
The Logic Outputs LO1 through LO6 are rated SIL2/IEC61508.  
Technical data of outputs see 3.2.4.



## 2.4 Power Supply

Each Monitor must be supplied with 24 volts dc (18..40 volts) from a power supply with protective separation, conforming to IEC 61131-2 requirements.

The Testgenerator E1698 is fed by an internal power rail.

Technical Data see 3.3.

## 2.5 Data Interface

Each of the Monitors E1666 and the Testgenerator E1698 have two female 9pole Sub-D connectors on the front side. On the left connector are a PROFIBUS interface (with standard pinning) and a RS232 interface (non standard pinning) implemented. On the right connector a PROFIBUS interface with identical function as on the left connector is implemented.

### 2.5.1 PROFIBUS Interface for Status and Diagnostics of the System

The PROFIBUS interface reflects the standard PROFIBUS DP and serves for the upload of status and diagnostic information of the system to a PLC or DCS.

### 2.5.2 RS232 Interface with Interface Software IS-RS232-E16 (for OEM only)

The RS232 Interface in conjunction with the Interface-Software IS-RS232-E16 (available for OEM only) serves

- to edit parameters
- to configure parameter settings as \*.brp files
- to upload parameter settings from Monitors and Testgenerator as \*.brv files
- to download parameter settings from \*.brp or \*.brv files to the Monitors and the Testgenerator

### 2.5.3 RS232 Interface with Interface Software IS-RS232-E16-L2 (for End User)

The RS232 Interface in conjunction with the Interface-Software IS-RS232-E16-L2 (available for End Users) serves

- to upload parameter settings from Monitors and Testgenerator as \*.brv files
- to download parameter settings from \*.brv files to spare part Monitors and Testgenerators

**Note: Parameter settings cannot be changed.**

## **3 Technical Specifications**

### **3.1 Technical Data of Inputs**

#### **3.1.1 Technical Data of Speed Signal Inputs**

##### **3.1.1.1 Hall Sensor Inputs**

Maximum input frequency : 50 kHz  
Maximum signal voltage : 30 Vdc  
Input low : at < 3 volts  
Input high : at > 7 volts  
Impedance : approx. 5 kohms  
Sensor supply : approx. 13 Vdc, maximum 80 mamps  
The sensor inputs have the same common, but are free floating versus other potentials.  
They are powered by an internal power supply.

##### **3.1.1.2 Eddy Current Sensor Inputs or MPU Inputs**

Maximum input frequency : 30 kHz  
Maximum signal voltage : 30 volts  
Trigger hysteresis : 0.07 to 2.5 Vpp  
Impedance : approx. 47 kohms  
Sensor supply (only with versions E16x456.xx2): approx. 24 volts, maximum 120 mamps  
The sensor inputs have the same common, but are free floating versus other potentials.  
They are powered by an internal power supply.

#### **3.1.2 Technical Data of Direction Inputs**

Maximum signal Voltage : 30 volts  
Input low : at < 3 volts  
Input high : at > 7 volts  
Impedance : approx. 22 kohms  
Same Reference as Speed Signal Inputs.

#### **3.1.3 Technical Data of Binary Inputs (excluding Voter 1)**

Input high : 18..48 volts (nominal current at 24 volts: 6 mamps)  
Input low : < 3 volts or open input  
Reference : negative pole of power supply

#### **3.1.4 Technical Data of Binary Inputs of Voter 1**

Input high : 18..30 volts (nominal current at 24 volts: 45 mamps)  
Input low : < 3 volts or open input  
Reference : negative pole of power supply

## **3.2 Technical Data of Outputs**

### **3.2.1 Technical Data of Speed Sensor Signal Repeater Outputs**

High level : > 20 volts with max. load, (maximum 26 volts without load)  
Low level : < 2 volts, with max. load  
Maximum load: 1 kohm  
The outputs are short-circuit proof and free floating (also versus each other).  
The outputs are supplied by free floating power sources within the monitors.

### **3.2.2 Technical Data of Analog Outputs**

Range : 0/4...20 mamps  
Resolution : 12 Bit  
Maximum load : 500 ohms  
Linearity error : < 0.1%  
Temperature stability :  $\pm 0,02$  %/°C within a range of 0...60°C.  
The outputs are short-circuit proof and free floating (also versus each other).

### **3.2.3 Technical Data of Opto Relay Outputs**

Maximum rating : 50 volts dc / 50 mamps.  
Outputs are passive, short-circuit proof and free floating (also versus each other). They must be supplied externally.

Note:

In case of short circuit the output is latched to tristate until power supply of the monitor has been switched off and on.

### **3.2.4 Technical Data of Logic Outputs**

The outputs are fed from the system power supply.  
Reference potential: M (negative pole of power supply).  
High level : Power supply L+ minus 2 volts  
Low level : < 3 volts  
Maximum output current : 50 mamps  
Outputs are short-circuit proof.

Note:

In case of short circuit the output is latched to tri state until power supply of the monitor has been switched off and on.

### **3.2.5 Technical Data of Trip Lines IV, V, VI**

Maximum rating : 50 volts dc / 300 mamps.

Outputs are passive, short-circuit proof and free floating. They must be supplied externally.

### **3.2.6 Technical Data of Trip Lines I, II, III**

Maximum rating : 50 volts dc / 3 amps / 75 watts

Maximum rating for DC13-applications : 24 volts / 3 amps

Outputs are not short-circuit proof (permanent currents exceeding 8 amps will destroy outputs).

Impedance : 10 kohms versus M (negative pole of power supply)

For inductive type loads, external spark extinguishing means must be provided.

Total response time (trip relays de-energize to trip) from trip event until trip circuits are in trip condition : < 15 milliseconds.

### 3.3 Technical Data of Power Supply

3x 24 volts dc / 0.5 amps (18...40 volts) from a power supply with protective separation, conforming to IEC 61131-2 requirements.  
Maximum consumption of system : 20 watts

### 3.4 Installation Conditions

Ambient temperature in operation : 0°C..+55°C  
Ambient temperature in storage: -20°C..+85°C  
Relative humidity < 80%  
To be installed in dry cabinets in air-conditioned rooms

### 3.5 Protection Grade

Insulation Class III  
Version E16A456 and E16E456 : IP20  
Version E16G456: IP65 resp. NEMA4

### 3.6 Connectors

Plug-In Cage-Clamp Connectors, type Phoenix Combicon FK-MLP1,5/...ST-3,5, fitting for:

Conductor cross section solid min.:	0.2 mm <sup>2</sup>
Conductor cross section solid max.:	1.5 mm <sup>2</sup>
Conductor cross section stranded min.:	0.2 mm <sup>2</sup>
Conductor cross section stranded max.:	1.5 mm <sup>2</sup>
Conductor cross section stranded, with ferrule without plastic sleeve min.:	0.25 mm <sup>2</sup>
Conductor cross section stranded, with ferrule without plastic sleeve max.:	1.5 mm <sup>2</sup>
Conductor cross section stranded, with ferrule with plastic sleeve min.:	0.25 mm <sup>2</sup>
Conductor cross section stranded, with ferrule with plastic sleeve max.:	0.75 mm <sup>2</sup>
Conductor cross section acc. to AWG/kcmil min.:	No. 24
Conductor cross section acc. to AWG/kcmil max.:	No. 16
Minimum AWG according to UL/CUL:	28
Maximum AWG according to UL/CUL:	16

### 3.7 Conformity to Standards

2006/42/EU  
SIL2/IEC61508, DIN EN ISO 13849-1:2008 Cat 3 PL e, API 670, API 672  
2006/95/EU, EN 61010-1,  
2004/108/EU, EN 61000-6-2, EN 61000-6-4, IEC 611311-2

### 3.8 Dimensions of one rack of System E16A456




Figure 7: Dimensions of System E16A456

### 3.9 Dimensions of system E16E456




Figure 8: Dimensions of System E16E456

### 3.10 Dimensions and Features of E16G456 Enclosure

Overall Dimensions (including mounting lugs):

Height: 510 mm  
Width: 410 mm  
Depth: 270 mm

Glazed Window with size 360 by 410 mm

Material: Fiberglass reinforced plastic




Figure 9: Dimensions of E16G456 Enclosure

### 3.11 Weight of E16x456

E16A456: 3,2 kg  
E16E456: 3,9 kg  
E16G456: 13,2 kg



## **4 Safety Notes for Installation and Operation**

### **4.1 Safety Notes for Installation**

This unit has been designed and inspected according to standards DIN EN 61010-1 (VDE 0411-1).

Observe these instructions and wiring diagrams carefully, to ensure this standards and safe operation of the machine.

The installation must be done only by adequately qualified personnel and with power supply switched off.

#### **4.1.1 General Instructions**

Specifically, connect the PE terminal X01.1 to a safe ground potential.

Do not open the instrument. Connections and all programming are done from outside. When removing it from its enclosure however, from whatever reason, make sure that power is switched off.

The instrument may be installed in any position, but not in the immediate neighborhood of interfering sources.

Speed signal leads must be carefully shielded, and should not be run in bundles with power or relay control leads.

Each speed signal must have its own screen.

#### **4.1.2 EMI**

The unit complies with all relevant regulations, as determined by the Policy of the European Committee for Electrotechnical Standardization (CENELEC), for the Electromagnetic Compatibility (2004/108/EU). Testing and inspection has been performed according to Standards IEC 61000-4-2 and IEC 61326-3-2. Thereby, the product meets all requirements to be marked by the CE sign.

Specifically to be observed:

Terminals must be kept off all undue access.

Terminals must be protected against electrostatic discharge.

Power supply and all input and output leads must be protected overvoltage.

## **4.2 Safety Notes for Operation**

### **4.2.1 Safety Notes on Commissioning**

The commissioning must be done only by adequately qualified personnel and with power supply switched off.

On initial operation of the monitored machine the operator must ensure proper function of the measurement chains.

This includes checking of the correct speed display and of the trip release due to a real overspeed condition.

If voter inputs are used the correct trip release due to external trip condition must be verified.

The parameter settings must be documented and protected against unauthorized changes.

## 5 Description of Monitor E1666

### 5.1 Display and Frontside Operational Elements

#### 5.1.1 Front View of Monitor E1666




Figure 10: Front View of Monitor E1666

#### 5.1.2 Status-LEDs

LED1	steady on:	Trip
LED2	steady on:	no Trip, SP1A is valid
	blinking:	SP1B is valid
LED3	steady on:	see parameter P05.05 of E1666
	blinking:	one only of three input channels measures zero speed
LED4		see parameter P05.05 of E1666

#### 5.1.3 Display during Test Procedures

- FC-1 : Frequency generator tests Input "Forced Trip"
- FC-3.1 : Trip-Line I is tested (relay I to Trip-Condition)
- FC-3.2 : Trip-Line II is tested (relay II to Trip-Condition)
- FC-3.4 : Trip-Line III is tested (relay III to Trip-Condition)

SELF : Monitor self-test

#### 5.1.4 Values accessible during normal operation

Values accessible during normal operation (Standard Display Mode):

with key  $\Delta$  : the value of SP1

with key  $\nabla$  : the value of SP2

with keys  $\Delta$  and  $\text{E}$  together: maximum stored speed value

with keys  $\nabla$  and  $\text{E}$  together: minimum stored speed value

**Note:**

with key  $\text{E}$  : reset of stored minimum/maximum value reset

with keys  $\text{E}$  and  $\text{E}$  together: reset of non persistent events (if enabled)

with keys  $\Delta$  and  $\nabla$  together: toggle between Standard and Special Display Mode 1

with keys  $\Delta$  and  $\text{P}$  together: toggle between Standard and Special Display Mode 2

#### 5.1.5 Display of Firmware release state and CRC-Parameter-Checksum of Monitor

With key  $\text{P}$  pressed longer as 5 seconds, the firmware release state and the CRC-Parameter-Checksum will be shown in a scrolled display:

A.0433 (firmware ID)

U.\_\_\_xx (xx = firmware version number)

D.uu\_\_ (uu = day)

D.\_vv\_ (vv = month)

D.\_\_\_ww (ww = year of firmware release state)

C.abcd (abcd = CRC-Parameter-Checksum)

### 5.1.6 Special Display Mode 1

Toggle between Standard and Special Display Mode 1 by pressing keys  $\Delta$  and  $\nabla$  together. In Special Display Mode 1 the measured speed values of sensors A, B, C can be shown individually as well as the signal level of the main sensor.

Toggle between the four values with  $\square$  .

The LED assigned to the specific speed value is blinking (see table).

with Monitor	LED assigned to			
	speed value of sensor:			signal level (in xx.x volts)
	LED1	LED2	LED3	LED4
A	A	C	B	A
B	B	A	C	B
C	C	B	A	C

Note :

If signal level (LED4 blinking) is selected, without a key pressed the median signal value is displayed.

The maximum measured signal level is then displayed with key  $\Delta$  .

The minimum measured signal level is then displayed with key  $\nabla$  .

Minimum, maximum and median values are dynamically updated with a sample rate of approx. 1 second.

### 5.1.7 Special Display Mode 2

Toggle between Standard and Special Display Mode 2 by pressing keys  $\Delta$  and  $\square$  together.

In Special Display Mode 2 LED1 and LED4 are blinking.

This display mode is only used for trouble shooting, if external signals are missing and the monitor displays the Event code E.0.4.0.0 .

### 5.1.8 Frontside Reset of Alarms and Event codes

Resetting of (no longer valid) alarms and event codes is done by pressing keys  $\square$  and  $\triangleleft$  together (if enabled in step P00.02).

### 5.1.9 Data Interface

Two 9pole Sub-D for PROFIBUS (RS232 only on left connector).

Note:

For RS232, adapter L3D02 or cable L3D05 must be used

## 5.2 Functions of Monitor E1666

For a detailed description of the individual functions refer to chapter 8.

### 5.2.1 Speed Measurement

Each Monitor receives the signal from the three sensors and calculates the speed from each signal. For the further evaluation it selects (depending on parameter settings) the calculated speed value derived of its own sensor or the median value of all three speed values.

Speed calculation is done by measuring the time in between the pulses. The minimum measurement time is 5 milliseconds.

To compensate for an imperfect gear, a predivider may be introduced to reduce the signal frequency to 1 pulse per revolution.

### 5.2.2 Functions for Overspeed Protection

Overspeed protection is done by:

- Monitoring of Sensors
- Monitoring versus Lowspeed as protection versus incorrect mounting or fault of speed sensors
- Monitoring versus overspeed

### 5.2.3 Functions for External Trip by Voters

Trip is released, if one of the voters detects an external trip condition.

Voters may be configured as 1oo2, 2oo2, 2oo3 or 3oo3. High or low Input-Level as trip condition and response time is selectable.

### 5.2.4 Permanent Monitoring Functions

Each Monitor E1666 has the following permanent monitoring functions:

- Sensor monitoring (see parameter group P02.xx)
- Overspeed monitoring SP1 (see parameter group P03.xx)
- Lowspeed monitoring SP2 (see parameter group P04.xx)
- Speed limit monitoring SP3 (siehe parameter group P05.xx)
- Trip-Line monitoring (see P07.00 und P07.01)
- Forward/Reverse monitoring of sense of rotation (see P07.02 and P07.03)
- Current monitoring of analog output (only with E16x456.2xx, see P08.06)
- Monitoring of external trip release signals (see parameter group P10.xx and with E16x456.x2x parameter groups P11.xx through P15.xx)

### 5.2.5 Functional Tests

The Testgenerator E1698 initiates cyclic automatic test sequences which incorporates the Monitors E1666. These test sequences may be initiated also by an external signal or manually by the frontpanel of the Testgenerator.

Performed functional tests are:

- Trip-Line test sequence (de-energize of Trip-Lines I, II and III, see chapter 6.2.3)
- Monitor test sequence (overspeed test of SP1 and trip of Monitor, see chapter 6.2.2)

If during the Trip-Line test sequence a fault is detected, the system response will be according the setting of parameter P03.01 of E1698.

If during the Monitor test sequence a fault is detected, the system response will be according the setting of parameter P02.03 of E1698 respective P03.02 of E1666.

### 5.2.6 Selftest of Monitor

Selftest is performed at an interval of 2 hours. Execution of Selftest is signaled on display with message SELF. Selftest of the Monitors are inhibited versus each other.

The Selftest routine includes:

- CPU RAM-Test
- CPU EEPROM-Test
- CPU Command-Test
- CPU Register-Test
- Voter Input Signal-Test

If the Selftest detects a malfunction, the monitor is set to trip-status.

## 6 Description of Testgenerator E1698

### 6.1 Display and Frontside Operational Elements

#### 6.1.1 Front View of Testgenerator E1698




Figure 11: Front View of Testgenerator E1698

#### 6.1.2 Status-LEDs

LED1 blinking:	Test of Monitor A resp. Trip-Line I
steady on:	Monitor A signalizes Trip
LED2 blinking:	Test of Monitor B resp. Trip-Line II
steady on:	Monitor B signalizes Trip
LED3 blinking:	Test of Monitor C resp. Trip-Line III
steady on:	Monitor C signalizes Trip
LED4 blinking:	Test in preparation
steady on:	Monitor-AutoTest-Mode on
steady off:	Monitor-AutoTest-Mode off

### 6.1.3 Display during Test Procedures

FC-1 : Frequency generator tests Input "Forced Trip"  
FC-3.0 : Trip-Line Test in preparation  
FC-3.1 : Test Generator is testing Trip-Line I (relay I of all Monitors to Trip-Condition)  
FC-3.2 : Test Generator is testing Trip-Line II (relay II of all Monitors to Trip-Condition)  
FC-3.4 : Test Generator is testing Trip-Line III (relay III of all Monitors to Trip-Condition)

FC-3.3 : Inputs Test I and II are active (but test is inhibited)  
FC-3.5 : Inputs Test I and III are active (but test is inhibited)  
FC-3.6 : Inputs Test II and III are active (but test is inhibited)  
FC-3.7 : Inputs Test I and II and III are active (but test is inhibited)

FC-5.1 : Non-coincidence of test outputs detected  
FC-5.2 : Input Test Lock is active  
FC-5.6 : Input Test Lock is longer than 10 minutes active

SELF : Test-Generator self-test

### 6.1.4 Values accessible during normal operation

with key  $\Delta$  : the value of test-speed 1 resp. SP1A,  
with key  $\nabla$  : the value of test-speed 2 resp. SP1B,  
with keys  $\nabla$  and  $\text{E}$  together: time remaining (in XXXX.X minutes) till start of the next Monitor-Test-Sequence),  
with keys  $\Delta$  and  $\text{E}$  together: time remaining (in XXXX.X minutes) till start of the next Trip-Line-Test-Sequence).

### 6.1.5 Display of Firmware release state and CRC-Parameter-Checksum of Monitor

with key  $\text{P}$  pressed longer as 5 seconds, the firmware release state and the CRC-Parameter-Checksum will be shown in a scrolled display:

- A.0339 (firmware ID)
- U.\_ \_xx (xx = firmware version number)
- D.uu\_ \_ (uu = year )
- D.\_vv\_ (vv = month )
- D.\_ \_ww (ww = day of firmware release state)
- C.abcd (abcd = CRC-Parameter-Checksum)

### 6.1.6 Frontside Reset of Alarms and Event codes

Resetting of (no longer valid) alarms and event messages is done by pressing keys  $\leftarrow$  and  $\text{E}$  simultaneously.

### 6.1.7 Manual Start of a Monitor-Test Sequence

The test routine can be activated from the front of the test generator by pressing keys  $\text{P}$  and  $\leftarrow$  simultaneously.

### 6.1.8 Manual Start of a Trip-Line-Test Sequence

The test routine can be activated from the front of the test generator by pressing keys  $\text{P}$  and  $\nabla$  simultaneously.

### 6.1.9 Data Interface

9-pole Sub-D for PROFIBUS and RS232 (only on left connector).



## 6.2 Functions of Testgenerator 1698

For a detailed description of the individual functions refer to chapter 9.

### 6.2.1 Permanent Monitoring of Feedbacks

The Monitors signalize their trip respective warning status to the Testgenerator. The status of the three feedback signals from the Valve Control Circuits is also signalized to the Testgenerator. With system E16x456 the Valve Control Circuit feedback is in trip state as long as no external valve command is active. With the first valve command active, the feedback changes to no trip state. The Testgenerator permanently monitors these signals and will release its alarm outputs "System Warning Alarm 1" and "System Warning Alarm 2", if one or more of these signals do not show the expected state.

The sequence of the Monitor Test is inhibited during channel warning alarm of the monitors.

The sequence of the Trip-Line Test is inhibited during channel warning alarm of the monitors and during Valve Control Circuit fault.

### 6.2.2 Monitor-Test Sequence

During the Monitor-Test Sequence each monitor is sequentially subjected to a test sequence consisting of two simulated test-speeds followed by a 'Forced Trip' signal.

- Step 1: Each Monitor is sequentially provided with a test-speed 1 ( $n > SP1$ ) to which the Monitor under test must respond with trip release.
- Step 2: Each Monitor is sequentially provided with a test-speed 2 ( $n < SP1$ ) to which the Monitor under test must not respond with trip release.
- Step 3: The 'Forced Trip' control input of each Monitor is sequentially activated to which the Monitor under test must respond with trip release. During this step the Monitor is provided with test-speed 2 ( $n < SP1$ ).

In the event of an incorrect response the test will be discontinued and the Testgenerator releases the System Warning Alarm 1 and 2.

If variable setpoint SP1var is active, the test may be optionally performed according to the following steps:

- Step 1: Each Monitor is sequentially provided with a test-speed 1 ( $SP1A + 5 \text{ RPM}$ ) to which the Monitor under test must respond with trip release.
- Step 2: Each Monitor is sequentially provided with a test-speed 2 ( $SP1B - 5 \text{ RPM}$ ) to which the Monitor under test must not respond with trip release.
- Step 3: The 'Forced Trip' control input of each Monitor is sequentially activated to which the Monitor under test must respond with trip release. During this step the Monitor is provided with test-speed 2 ( $SP1B - 5 \text{ RPM}$ ).
- Step 4: Each Monitor is sequentially provided with a test-speed 3 ( $SP1A - 5 \text{ RPM}$ ) to which the Monitor under test must not respond with trip release.
- Step 5: Each Monitor is sequentially provided with a test-speed 4 ( $SP1B + 5 \text{ RPM}$ ) to which the Monitor under test must respond with trip release.

The time interval of these tests is programmable (see P02.02). The test sequence may also be started by an external signal „Start Auto Test Sequence“ or manually via frontside key-board of the Test-Generator.

### **6.2.3 Trip-Line-Test Sequence (Test of 2oo3 Solenoid Valve Block)**

The Testgenerator commands the Monitors to put sequentially the trip relays I, II or III to trip condition.

By doing so the designated Trip-Line to the 2oo3 Solenoid Valve is in trip condition.

The status of the 2oo3 Solenoid Valve is fed back to the Testgenerator.

The testing of Trip-Line I must provide the response of Solenoid Valve I.

The testing of Trip-Line II must provide the response of Solenoid Valve II.

The testing of Trip-Line III must provide the response of Solenoid Valve III.

In the event of an incorrect response the test will be discontinued and the Testgenerator releases the System Warning Alarm 1 and 2.

The interval between two automatic test sequences is selectable (see P03.00 of E1698). The test sequence may also be initiated by an external signal (terminal X08.5) or by frontpanel.

If externally initiated the sequence is executed automatically, subsequent after approx. 2 minutes the monitor test sequence is executed (see chapter 6.2.2).

### **6.2.4 Cross-check between CPUs of Test-Generator**

The Test-Generator incorporates two redundant CPUs. Both CPUs must perform identically to release a test sequence. In case of failure of one CPU no test is released, but System Warning Alarm 1 or 2 is released.

### **6.2.5 Selftest of CPUs**

Selftest is performed after each Monitor test sequence. Execution of Selftest is signaled on display with message SELF.

The Selftest of both CPU routine includes:

- CPU RAM Test
- CPU EEPROM Test
- CPU Command Test
- CPU Register Test

If the Selftest detects a malfunction, System Warning Alarm 1 or 2 is released.

## 7 Programming of the Modules

### 7.1 Programming of the Modules via Front Keyboard

Principle: Select a parameter via its ,name' **Pgg.ss**,  
 in that **gg** = Parameter-group number and  
**ss** = Step-number within the group,

then display the value and alter if required.

Procedure:

Initiate programming phase by pressing keys **[P]** and **[E]** together;  
 instead of the normal display P00.00. appears

Select the group or step number with keys **[Δ]**, **[∇]**.

Switch between Groups and Step Fields with the **[◀]** key.

Current value of the Parameters is displayed with key **[E]**.


Select active position with the **[◀]** key.

Adjust the number in the active field with keys **[Δ]**, **[∇]**.

Acknowledge and set with key **[E]**, Discard (original value remains) with key **[P]**.

Return to operational mode with the **[P]** key. The display then returns to the current 'is' speed  
 (with E1666) resp. to the current test-speed (with E1698)

**See example below:** Change parameter P01.01 from 2386 to 2387.



## 7.2 Programming of the Modules via RS232-Interface

1. adapter L3D02 with cable L3D03 by BRAUN

Note:

- Adapter L3D02 has male connectors on both sides.
- Cable L3D03 has female connectors to L3D02 and to PC.

or

2. customized cable with connections PC (female connector) to E16 (male connector):

PC pin	2	to	E16 pin	2
	3	to		7
	5	to		5

(of 9 pole Sub-D connectors)

Note:

- The RS232-Interface serves only for parameter programming purposes, not for transmission of current data. States, alarms and measurement data are transmitted via PROFIBUS-Interface only.

## 7.3 Default Values

If not specified otherwise, the unit is supplied with default values as listed in the summary of parameters. In process of installation, the setting of its parameters inevitably must be adapted to the correct values according its application.

## 8 Parameters of Monitor E1666

### 8.1 Summary of parameters and their default values



Param. No.	Default value	Parameter Function
<b>P00.xx</b>		Code figure, Parameter Lock
P00.00	0000	Code figure
.01	0000	New code figure
.02	1	Parameter Lock : 0: locked / 1: enabled
.03	1	Front side Reset: 0: not possible / 1: possible
<b>P01.xx</b>		Input, Scaling
P01.00	0	Reserved for future applications
.01	10000	Value of nominal input frequency in Hz
.02	0	Decimals of speed value for SP2, SP3 PROFIBUS-Output
.03	10000	Nominal speed in RPM
.04	00001	Lower limit of the speed range
.05	001	Predivider : 001 ... 255
.06	0	Reserved for future applications
.07	0	Decimals for acceleration
.08	01000	Maximum acceleration in XXXX or XXX.X RPM/sec
.09	5	No. of acceleration measurements included in calculation of SP1var: 1 .. 5
<b>P02.xx</b>		Display, Starter, Tests
P02.00	0	Reserved for future applications
.01	0.3	Display updating sequence : 0.1 ... 9.9 sec
.02	000	Starter time period: 000 ... 999 sec
.03	1	Reserved for future applications
.04	4	Sensor monitoring: 0 ... 4 (see parameter description)
.05	1	Mode of Sensor Monitoring: 0 ... 7 (see parameter description)
.06	1	Lowspeed Monitoring "n < SP2": 0 ... 4 (see parameter description)
.07	4	Mode of Speed Comparison Test : 0 ... 5 (see parameter description)
.08	030	Permissible Speed Difference between Sensors (in xxx RPM)
.09	05	Number of errors before reporting
.10	1	Monitor Warning Alarm at Trip: 0 ... 4 (see parameter description)
.11	1	Latch Monitor Warning Alarm: 0: no / 1: yes, all alarms / 2: yes, first one only
<b>P03.xx</b>		Overspeed Alarm SP1
P03.00	00010	Setpoint SP1A in RPM
.01	05.0	Hysteresis bandwidth (XX.X % of SP1A)
.02	0	Alarm to be latched / energized or de-energized to trip: 0 ... 3 (see parameter description)
.03	00001	Setpoint SP1B in RPM
.04	0	Setpoint SP1var : 0: not active / 1: active
		Continued on next page

Param. No.	Default value	Parameter Function
<b>P04.xx</b>		Low Speed Alarm SP2
P04.00	00100	Setpoint SP2 in RPM
.01	05.0	Hysteresis bandwidth (XX.X % of SP2)
.02	0	Fix value = 0, do not change
<b>P05.xx</b>		Alarm SP3
P05.00	00003	Setpoint SP3 in RPM
.01	05.0	Hysteresis bandwidth (XX.X % of SP3)
.02	0	Hysteresis position: 0: above / 1: below
.03	1	Relay state at "n > SP3": 0 ... 3 (see table)
.04	0	Alarm state at sensor fault: 0: acc. to speed / 1: "n < SP" / 2: "n > SP"
.05	1	Setting of LEDs to status "n > SP3": 0: LED3 on / 1: LED4 on
<b>P06.xx</b>		Eddy sensor
P06.00	00000	Reserved for future application
.01	00.0	Eddy sensor input check: input voltage upper limit in xx.x volts
.02	00.0	input voltage lower limit in xx.x volts
.03	000	current drain upper limit in xxx mamps
.04	000	current drain lower limit in xxx mamps
.05	0.0	Eddy sensor input hysteresis in x.x volts
<b>P07.xx</b>		Trip-Lines, Forward / Reverse Detection
P07.00	0	Trip-Line Monitoring: 0 ... 2 (see parameter description)
.01	0	Signal level Trip-Feedback: 0: low = Trip / 1: high = Trip
.02	1	Forward / Reverse Detection Input level: 0: low = forward / 1: high = forward
.03	1	Forward / Reverse relay state: 0: de-energized = forward / 1: energized = forward
.04	0	Reserved for future application
<b>P08.xx</b>		Analog Output
P08.00	10000	High end speed value
.01	00000	Low end speed value
.02	1	Zero level: 0: dead zero / 1: live zero
.03	0	Output level at sensor fault: 0: no change / 1: min / 2: max
.04	0	Output direction: 0: 0/4 ... 20 ma / 1: 20 ... 4/0 ma
.05	0	Output response to test-speed: 0: test-speed / 1: frozen
.06	0	Test of Analog Output value: 0: no / 1: yes
<b>P09.xx</b>		Reserved for future application
P09.00	0	Reserved for future application
<b>P10.xx</b>		Voter No. 1 and LO1
P10.00	0	Operation Mode: 0 ... 5 (see table)
.01	0	Input Truth Level: 0: high = Trip / 1: low = Trip
.02	0	Voting logic: 0: 1oo2 / 1: 2oo2 / 2: 2oo3 / 3: 3oo3
.03	0	Truth Time until Trip: 0 ... 7 (see table)
.04	0	Trip latched: 0: no / 1: yes
.05	0	Delay of Antivalence Alarm: 0 ... 9 (see table)
.06	00110	Value for setpoint SPV1
		Continued on next page

Param. No.	Default value	Parameter Function
<b>P11.xx</b>		
Voter 2 and LO2		
P11.00	0	Operation Mode: 0 ... 5 (see parameter description)
.01	0	Input Truth Level: 0: high = Trip / 1: low = Trip
.02	0	Voting logic: 0: 1oo2 / 1: 2oo2 / 2: 2oo3 / 3: 3oo3
.03	0	Truth Time until Trip: 0 ... 7 (see parameter description)
.04	0	Trip latched: 0: no / 1: yes
.05	0	Delay of Antivalence Alarm: 0 ... 9 (see parameter description)
.06	00120	Value for setpoint SPV2
<b>P12.xx</b>		
Voter 3 and LO3		
P12.00	0	Operation Mode: 0 ... 5 (see parameter description)
.01	0	Input Truth Level: 0: high = Trip / 1: low = Trip
.02	0	Voting logic: 0: 1oo2 / 1: 2oo2 / 2: 2oo3 / 3: 3oo3
.03	0	Truth Time until Trip: 0 ... 7 (see parameter description)
.04	0	Trip latched: 0: no / 1: yes
.05	0	Delay of Antivalence Alarm: 0 ... 9 (see parameter description)
.06	00130	Value for setpoint SPV3
<b>P13.xx</b>		
Voter 4 and LO4		
P13.00	0	Operation Mode: 0 ... 5 (see parameter description)
.01	0	Input Truth Level: 0: high = Trip / 1: low = Trip
.02	0	Voting logic: 0: 1oo2 / 1: 2oo2 / 2: 2oo3 / 3: 3oo3
.03	0	Truth Time until Trip: 0 ... 7 (see parameter description)
.04	0	Trip latched: 0: no / 1: yes
.05	0	Delay of Antivalence Alarm: 0 ... 9 (see parameter description)
.06	00140	Value for setpoint SPV4
<b>P14.xx</b>		
Voter 5 and LO5		
P14.00	0	Operation Mode: 0 ... 5 (see parameter description)
.01	0	Input Truth Level: 0: high = Trip / 1: low = Trip
.02	0	Voting logic: 0: 1oo2 / 1: 2oo2 / 2: 2oo3 / 3: 3oo3
.03	0	Truth Time until Trip: 0 ... 7 (see parameter description)
.04	0	Trip latched: 0: no / 1: yes
.05	0	Delay of Antivalence Alarm: 0 ... 9 (see parameter description)
.06	00150	Value for setpoint SPV5
<b>P15.xx</b>		
Voter 6 and LO6		
P15.00	0	Operation Mode: 0 ... 5 (see parameter description)
.01	0	Input Truth Level: 0: high = Trip / 1: low = Trip
.02	0	Voting logic: 0: 1oo2 / 1: 2oo2 / 2: 2oo3 / 3: 3oo3
.03	0	Truth Time until Trip: 0 ... 7 (see parameter description)
.04	0	Trip latched: 0: no / 1: yes
.05	0	Delay of Antivalence Alarm: 0 ... 9 (see parameter description)
.06	00160	Value for setpoint SPV6
		Continued on next page

Param. No.	Default value	Parameter Function
<b>P16.xx</b>		Reserved for future application
P16.00	0	Reserved for future application
.01	0	Reserved for future application
.02	0	Reserved for future application
.03	0	Reserved for future application
.04	0	Reserved for future application
.05	0	Reserved for future application
.06	00000	Reserved for future application
<b>P17.xx</b>		Data Interface
P17.00	016	PROFIBUS-Interface Device no.
.01	0	Address Offset for second Profibus Interface



Parameter Group P00.xx of Monitor E1666 Code Figure, Parameter Lock, Frontside Reset of Alarms	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P00.00</b> <b>Code Figure</b> Range: 0000 .. 9999	If the parameters are locked (see P00.02), the code figure must be entered prior to any change of other parameters. If the code figure is not correct, -E 1- is displayed. Without code figure and P00.02 : 0 the values of all parameters may be inspected, but not changed.
<b>P00.01</b> <b>New Code Figure</b> Range: 0000 .. 9999	A new code figure may be set in P00.01. Then it replaces the previous one.
<b>P00.02</b> <b>Parameter Lock</b> Range: 0 .. 1	Setting 0 : Parameters are locked, change only possible with code figure 1 : Parameters unlocked, change of parameter values possible
<b>P00.03</b> <b>Frontside Reset of Alarms</b> Einstellbereich: 0 .. 1	Setting 0 : Frontside reset of alarms not possible 1 : Frontside reset of alarms possible with keys  and  .

Parameter Group P01.xx of Monitor E1666 Input Scaling and Measurement Configuration	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P01.00</b> Reserved for future applications	
	<p><b>Description of Scaling:</b> Scaling defines the relationship between the input signal frequency (in terms of Hz), and the corresponding display (in terms of RPM). Of course, they must refer to the same operation level. This reference point is recommended close to the high end of the intended operation range. In later operation, however, it may be overrun without error.</p> <p>Example: 1500 Hz corresponds to 3000 RPM :  <div style="margin-left: 100px;">⇒      Step P01.01 : setting 01500  Step P01.03 : setting 03000</div></p>
<b>P01.01</b> <b>Nominal Input Frequency [Hz]</b> Range: 00001 .. 99999	See description of Scaling.
<b>P01.02</b> <b>Decimals for P01.04, P04.00, P05.00 and for PROFIBUS Speed Data Output</b> Range: 0 .. 1	Setting 0 : Setting range for P01.04, P04.00, P05.00 : 00001 to 99999 RPM 1 : Setting range for P01.04, P04.00, P05.00 : 0000.1 to 9999.9 RPM
<b>P01.03</b> <b>Nominal speed [RPM]</b> Range: 00001 .. 99999	See description of Scaling.
<b>P01.04</b> <b>Lower Limit of the Speed Range</b> Range as defined in P01.02	If the monitored speed falls below the value entered here the measured value is given as 0 both for the display and the alarms. The lower limit of the speed range is entered in units of RPM.

Parameter Group P01.xx (continued) of Monitor E1666 Measurement Configuration	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P01.05</b> <b>Predivider</b> Range: 001 .. 255	The predivider is used only if the variable setpoint SP1var is active (P03.04 = 1). The predivider must then be set to the number of teeth of the gear wheel. The acceleration measurement is extended over one full rotation of the machine. <b>Note:</b> The predivider applies only to the primary measurement input. The two other measurement channels are not affected by the predivider.
<b>P01.06</b> Reserved for future application	
<b>P01.07</b> <b>Decimals for acceleration</b> Range: 0 .. 1	Setting 0 : setting of acceleration in XXXXX RPM/sec 1 : setting of acceleration in XXXX.X RPM/sec
<b>P01.08</b> <b>Maximum acceleration of the machine [RPM/sec]</b> Range: 00001 .. 99999 resp. 0000.1 .. 9999.9	Setting is done in RPM/sec. Value must be set to the maximum possible acceleration (dN/dt max) of the machine in the worst case scenario. See also description of step P03.04
<b>P01.09</b> <b>No of acceleration measurements included in calculation of SP1var</b> Range: 1 .. 5	Recommended value is 1 or 2 measurements (equals to a measurement time of 20 or 40 milliseconds at a speed of 3000 RPM). More measurements included will improve the stability of the calculated setpoint SP1var, but also result in a delayed update rate.

Parameter Group P02.xx of Monitor E1666 Display, Starter time, Sensor Failure Monitoring	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P02.00</b> Reserved for future application	
<b>P02.01</b> <b>Display updating sequence</b> Range: 0.1 .. 9.9 [s]	The display may have its own independent up-dating sequence, different from the response time used by other functions - again in the interests of stabilized and legible readings. Set the parameter to the time required in steps of 0.1 sec. Recommended value is 0.3 sec. The display value is determined by the duration of a cycle sequence. The rapid response of the alarms is not influenced by this procedure.
<b>P02.02</b> <b>Starter Time Period</b> Range: 000 .. 999 [s]	This step sets the starter time period (duration). The starter phase state for SP2 lasts from the beginning of the external starter signal plus the programmed time elapse following its end.
<b>P02.03</b> Reserved for future application	
<b>P02.04</b> <b>Sensor Monitoring (Current and Signal Level)</b> Range: 0 .. 4	A sensor fault will be reported according to the designated parameters and, if configured, latched until the reset is activated. Setting 0 : Monitoring disabled 1 : Not permissible 2 : Fault reported + Trip release, latched till reset 3 : Not permissible 4 : Fault reported without trip release (recommended setting)
<b>P02.05</b> <b>Mode of Sensor Monitoring</b> Range: 0 .. 7	Setting 0 : Without monitoring (see Note 3) 1 : Checks sensor current drain 2 : Checks signal voltage level at stand still (see Note 1) 3 : Current drain and voltage level 4 : Inductive sensor (MPU) 5 : Reserved for future use 6 : Eddy sensor voltage level (see Note 2) 7 : Eddy sensor voltage level and current drain (see Note 2)  <b>Note 1:</b> The voltage level check is only possible with BRAUN-sensor type A5S... . In this instance even at stand still a defective sensor or supply cable can be detected. <b>Note 2:</b> The signal voltage level (and current drain) is compared versus max/min-values as set in P06.01 to P06.04. <b>Note 3:</b> Selection of Setting 0 makes Step P02.04 meaningless.

**Parameter Group P02.xx (continued) of Monitor E1666**  
**Sensor Failure Monitoring**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<p><b>P02.06</b>  <b>Lowspeed Monitoring</b>  <b>"n &lt; SP2"</b>            Range: 0 .. 4</p>	<p><b>Safety Note:</b>  <b>The Lowspeed Monitoring "n &lt; SP2" is the only comprehensive protection versus a systematic fault of any type of speed sensor (no speed signal from sensor at running machine).</b>  <b>Setting of P02.06 = 0 is allowed only for test purposes during start-up of the machine. In normal operation P02.06 must be set to a value of 1 or 2 or 3 or 4.</b></p> <p><b>Function of Lowspeed Monitoring "n &lt; SP2":</b>            Following the end of the Starter phase (Start-Up Bridging) the measured speed must exceed the value set for SP2. If the measured speed n is then lower than SP2, trip is released.</p> <p><b>Function of Starter Plausibility Check:</b>            If</p> <ul style="list-style-type: none"> <li>• starter condition is true</li> <li>• and plausibility check is on</li> <li>• and speed exceeds 50% of overspeed setpoint SP1A</li> </ul> <p>then            Monitor Warning Alarm is released by plausibility check and event code E.3.0.1.0 is displayed.</p> <p><b>Setting</b></p> <ul style="list-style-type: none"> <li>0 : Monitoring switched off <b>(not permissible, see safety note above)</b></li> <li>1 : Trip and Alarm till rectified, starter plausibility check on</li> <li>2 : Trip and Alarm latched, starter plausibility check on</li> <li>3 : Trip and Alarm, till rectified / starter plausibility check off</li> <li>4 : Trip and Alarm latched / starter plausibility check off</li> </ul>

**Parameter Group P02.xx (continued) of Monitor E1666**  
**Sensor Failure Monitoring**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<p><b>P02.07</b>  <b>Speed Comparison</b>  <b>Evaluation Mode</b>            Range: 0 .. 5</p>	<p>Speed comparison of the 3 sensors enables:</p> <ul style="list-style-type: none"> <li>• Detection of incorrect installation of the sensor (distance from the tooth wheel too large or wrong position) even during the start-up bridging phase</li> <li>• Detection of a fading function of a sensor during normal operation</li> </ul> <p>Functionality:            Each Monitor has three measuring channels and receives the signals of all three sensors.</p> <p>Setting</p> <p>0 : only the primary sensor will be evaluated; no redundancy.            1 : Trip is released if primary sensor fault is detected.            2 : only error message is released if primary sensor fault is detected, but only speed value of primary sensor is used for further evaluation.            3 : not permissible            4 : only error message is released if primary sensor fault is detected, but the median value of the three speed values is used for further evaluation.            5 : same as setting 4, but a trip released due to deviation is latched.</p> <p>Setting 1 or 2 or 4 or 5:            During machine operation each Monitor compares its sensor input with those of its two neighbors. If the measured speed value of its own (primary) sensor in comparison with its two neighbors produces a discrepancy exceeding the tolerance level set at P02.08, the monitor's primary sensor will be reported as faulty.            However, should all three measured speed values deviate from each other for more than the specified tolerance, the monitor will release trip.</p> <p><b>Note:</b>            Setting P02.07 = 4 or 5 avoids a trip release caused by a sensor fault during the automatic test procedure and are recommended settings.</p> <p><b>Example:</b>            Monitor A is tested for overspeed, at the same time the signal from sensor B drops out. Monitor B reports an error, but continues to evaluate the signals from sensors A and C.</p>

**Parameter Group P02.xx (continued) of Monitor E1666**  
**Sensor Failure Monitoring**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>																														
<b>P02.08</b> <b>Permissible Speed Difference between Sensors</b> Range: 001 .. 999 [RPM]	Value for the permissible difference in RPM between the speed measurement of the primary sensor and that of the other two sensors before a fault is detected. <b>Note:</b> Primary sensor is the sensor the monitor supplies with power.																														
<b>P02.09</b> <b>Number of tests until alarm</b> Range: 01 .. 99	Number of consecutively failed speed comparison tests which may occur before an error message is issued. <b>Note:</b> At speeds lower than 50% of the nominal speed, the number of tests is automatically increased to avoid incorrect alarms during acceleration phase of the machine.  <b>Example for Setting of P02.07 = 4:</b> P02.08 = 030 (permissible difference between measured values = 30 RPM) P02.09 = 5 (Number of consecutive errors till error message issued)  With the example above an error message will be issued when the speed value of the primary sensor deviates by 30 RPM from the two other measured sensors five measurements in succession. When all three measurements of one monitor between themselves differ by more than 30 RPM (measurement of sensor A = 6031 RPM, of sensor B = 6000 RPM, of sensor C = 5969 RPM), the monitor will release trip.																														
<b>P02.10</b> <b>Monitor Warning Alarm also at Trip Condition</b> Range: 0 .. 4	Setting depends on how the alarm is used according the specific application for detection of SOE (sequence of events). <table border="1" data-bbox="587 1279 1410 1576"> <thead> <tr> <th>Setting</th> <th>Alarm at Overspeed-Trip</th> <th>Alarm at Voter-Trip</th> <th>Alarm at Trip due to Trip-Line-Monitoring</th> <th>Alarm at Lowspeed-Trip</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No</td> <td>No</td> <td>Yes</td> <td>Yes</td> </tr> <tr> <td>1</td> <td>Yes</td> <td>Yes</td> <td>Yes</td> <td>Yes</td> </tr> <tr> <td>2</td> <td>No</td> <td>No</td> <td>No</td> <td>Yes</td> </tr> <tr> <td>3</td> <td>Yes</td> <td>Yes</td> <td>No</td> <td>Yes</td> </tr> <tr> <td>4</td> <td>No</td> <td>No</td> <td>No</td> <td>No</td> </tr> </tbody> </table> <b>Note:</b> The Monitor Warning Alarm is always released in case of detected sensor fault.	Setting	Alarm at Overspeed-Trip	Alarm at Voter-Trip	Alarm at Trip due to Trip-Line-Monitoring	Alarm at Lowspeed-Trip	0	No	No	Yes	Yes	1	Yes	Yes	Yes	Yes	2	No	No	No	Yes	3	Yes	Yes	No	Yes	4	No	No	No	No
Setting	Alarm at Overspeed-Trip	Alarm at Voter-Trip	Alarm at Trip due to Trip-Line-Monitoring	Alarm at Lowspeed-Trip																											
0	No	No	Yes	Yes																											
1	Yes	Yes	Yes	Yes																											
2	No	No	No	Yes																											
3	Yes	Yes	No	Yes																											
4	No	No	No	No																											
<b>P02.11</b> <b>Latching of Monitor Warning Alarm and Event Messages</b> Range: 0 .. 2	The Monitor Warning Alarm and the Event Display can be latched. Setting 0 : no 1 : yes, in this case all occurring events are shown in the display as combinations 2 : yes, in this case only the first occurring event is displayed																														

Parameter Group P03.xx of Monitor E1666 Overspeed Alarm SP1	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P03.00</b> <b>Overspeed Setpoint SP1A</b> Range: 00001 .. 99999	The numerical value for the setpoint is set in terms of RPM.
<b>P03.01</b> <b>Alarm Hysteresis Width</b> Range: 00.1 .. 99.9	<p><b>Hysteresis of Overspeed Setpoint</b></p> <p>The hysteresis is the margin between condition "excess" (&gt;) and "no excess" (&lt;), defined by its bandwidth.</p> <p><b>Width of the hysteresis</b></p> <p>The width of hysteresis is set as a percentage of the switching point. The position of the hysteresis for SP1 is determined beneath the setpoint.</p> <p>Example:</p> <p>With 5% Hysteresis and a setpoint of 10000 RPM an overspeed alarm is issued once 10000 RPM is exceeded and ceases should the speed drop below 9500 RPM.</p> <p>Note:</p> <p>The hysteresis is always calculated for SP1A.</p> <p>If SP1B is used and the alarm is not latched, hysteresis must be chosen that</p> <ul style="list-style-type: none"> <li>• it is big enough to include SP1B to avoid bouncing of the trip relays</li> <li>• it is small enough to that the return point is not lower than normal operating speed.</li> </ul> <p>Example:</p> <p>SP1A=3240 RPM, SP1B=3090 RPM, normal operating speed=3000 RPM.</p> <p>Then hysteresis must be minimum <math>(3240-3090)/3240 = 4.7\%</math> and maximum <math>(3240-3000)/3000 = 7.9\%</math>.</p>
<b>P03.02</b> <b>Latching of Overspeed Alarm/ Energize or de-energize to Trip</b> Range: 0 .. 3	<p>The overspeed alarm can be latched until externally reset.</p> <p>The trip relays can be programmed to energize or to de-energize to trip (released by Overspeed or externally via Voter) condition.</p> <p>Setting</p> <ul style="list-style-type: none"> <li>0 : alarm not latched, trip relays de-energize to trip</li> <li>1 : alarm latched, trip relays de-energize to trip</li> <li>2 : alarm not latched, trip relays energize to trip</li> <li>3 : alarm latched, trip relays energize to trip</li> </ul>
<b>P03.03</b> <b>Overspeed Setpoint SP1B</b> Range: 00001 .. 99999	<p>The numerical value for the setpoint is set in terms of RPM.</p> <p>SP1B is always valid as long as the input „SP1B valid" is true.</p>



**Parameter Group P03.xx (continued) of Monitor E1666**  
**Overspeed Alarm SP1**

Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings														
<p><b>P03.04</b>  <b>Overspeed Setpoint SP1var</b>  <b>not active / active</b>                      Range: 0 .. 1</p> <p><b>Attention:</b>  <b>If P03.04 = 1: The value of SP1A (P03.00) must not be lower than the value of SP1B (P03.03), else SP1B will always be valid during acceleration phase.</b></p>	<p>Setting                      0 : overspeed setpoint SP1var is not active                      1 : overspeed setpoint SP1var is active</p> <p>If the overspeed setpoint SP1var is not active, then SP1A is valid (respective SP1B as long as the input "SP1B valid" is true).                      If the overspeed setpoint SP1var is active, it is calculated depending on the measured acceleration in between the limits of SP1A and SP1B.                      If acceleration <math>dN/dt = 0</math> , then <math>SP1var = SP1A</math>.                      If acceleration <math>dN/dt = dN/dt \text{ max}</math> , then <math>SP1var = SP1B</math>.</p> <p>Example for values of SP1var:  <math>dN/dt \text{ max} = 300 \text{ RPM/sec}</math>  <math>SP1A = 3240 \text{ RPM}</math> (at acceleration rate of <math>0 \text{ RPM/sec}</math>)  <math>SP1B = 3090 \text{ RPM}</math> (at acceleration rate of <math>300 \text{ RPM/sec}</math>)</p> <table border="1" data-bbox="603 965 1347 1294"> <thead> <tr> <th>measured acceleration</th> <th>calculated value SP1var</th> </tr> </thead> <tbody> <tr> <td>300 RPM/sec</td> <td>3090 RPM</td> </tr> <tr> <td>240 RPM/sec</td> <td>3120 RPM</td> </tr> <tr> <td>180 RPM/sec</td> <td>3150 RPM</td> </tr> <tr> <td>120 RPM/sec</td> <td>3180 RPM</td> </tr> <tr> <td>60 RPM/sec</td> <td>3210 RPM</td> </tr> <tr> <td>0 RPM/sec</td> <td>3240 RPM</td> </tr> </tbody> </table> <p>See also graph below</p>	measured acceleration	calculated value SP1var	300 RPM/sec	3090 RPM	240 RPM/sec	3120 RPM	180 RPM/sec	3150 RPM	120 RPM/sec	3180 RPM	60 RPM/sec	3210 RPM	0 RPM/sec	3240 RPM
measured acceleration	calculated value SP1var														
300 RPM/sec	3090 RPM														
240 RPM/sec	3120 RPM														
180 RPM/sec	3150 RPM														
120 RPM/sec	3180 RPM														
60 RPM/sec	3210 RPM														
0 RPM/sec	3240 RPM														




Figure 12:  
 SP1 as a variable  
 of the acceleration

Parameter Group P04.xx of Monitor E1666 Lowspeed Alarm SP2	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P04.00</b> <b>Lowspeed Setpoint SP2</b> Range: 00001 .. 99999	The numerical value for the setpoint SP2 is expressed as RPM.
<b>P04.01</b> <b>Alarm Hysteresis Width</b> Range: 00.1 .. 99.9	<p>The hysteresis is the margin between condition "excess" (&gt;) and "no excess" (&lt;), defined by its bandwidth.</p> <p>The width of hysteresis is set as a percentage of the switching point.</p> <p>The position of the hysteresis of SP2 is determined above the setpoint.</p> <p><b>Example:</b> With 5% Hysteresis and a setpoint of 100 RPM a Lowspeed alarm is issued once speed drops below 100 RPM and ceases once speed exceeds 105 RPM.</p>
<b>P04.02</b> Fix value = 0, do not change	

Parameter Group P05.xx of Monitor E1666 Alarm SP3	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P05.00</b> <b>Setpoint SP3</b> Range: 00001 .. 99999	The numerical value for the setpoint SP3 is expressed as RPM.
<b>P05.01</b> <b>Alarm Hysteresis Width</b> Range: 00.1 .. 99.9	The hysteresis is the margin between condition "excess" (>) and "no excess" (<), defined by its bandwidth. The width of hysteresis is set as a percentage of the switching point.
<b>P05.02</b> <b>Hysteresis position</b> Range: 0 .. 1	The hysteresis band for SP3 may be placed above or below setpoint. Setting 0 : Hysteresis above SP3 1 : Hysteresis below SP3
<b>P05.03</b> <b>Relay State at n &gt; SP3</b> Range: 0 .. 3	Setting 0 : Relay energized if n > SP3 1 : Relay de-energized if n > SP3 2 : Relay energized if n > SP3, output frozen at test 3 : Relay de-energized if n > SP3, output frozen at test
<b>P05.04</b> <b>Alarm State at Sensor Error Condition</b> Range: 0 .. 2	If a sensor fault is detected, alarm SP3 can be forced into a defined state. Setting 0: Alarm SP3 according to measured rotational speed 1: Alarm SP3 forced to state n < SP3 2: Alarm SP3 forced to state n > SP3
<b>P05.05</b> <b>Status of LEDs 3 and 4 for Alarm n &gt; SP3</b> Range: 0 .. 1	Assignment LED (red or green) to alarm state n > SP3. Setting 0 : LED3 (green) on at n > SP3 1 : LED4 (red) on at n > SP3

Parameter Group P06.xx of Monitor E1666 Eddy sensor input and MPU input	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P06.00</b> Reserved for future application	
	Eddy sensors must not be operated outside (manufacturer) specified limits of voltage level and supply current. These limits can be checked (see parameter P02.05).
<b>P06.01</b> <b>Input voltage upper limit</b> Range: 00.0 to 99.9	Input check:     input voltage upper limit     in xx.x volts
<b>P06.02</b> <b>Input voltage lower limit</b> Range: 00.0 to 99.9	input voltage lower limit     in xx.x volts
<b>P06.03</b> <b>Current drain upper limit</b> Range: 000 to 999	current drain upper limit     in xxx mamps
<b>P06.04</b> <b>Current drain lower limit</b> Range: 000 to 999	current drain lower limit     in xxx mamps
<b>P06.05</b> <b>Signal input hysteresis</b> Einstellbereich: 0.0 .. 2.5	Signal input hysteresis (sensitivity level) is set in x.x volts. The signal must be higher than the hysteresis to detect the speed. <b>Note:</b> <b>The hysteresis must be larger than the possible noise on the signal line in order to achieve a proper speed measurement.</b>  Note: with setting 0.0 hysteresis is approx 70 millivolts

Parameter Group P07.xx of Monitor E1666 Trip-Line-Monitoring, Rotational Direction Output	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P07.00</b> <b>Trip-Line-Monitoring</b> Range: 0 .. 2	If activated the Monitor checks the output of the Trip-Lines. If two or three Trip-Lines indicate trip condition the monitor moves to trip status (Trip Lock Function). Following the reset signal the monitor releases the trip state for one second. Within this time the feedback signal must respond correctly, otherwise the monitor returns to trip status. Setting 0 : Trip-Line-Monitoring not active 1 : Trip-Line-Monitoring active, with response time until trip = 50 msec 2 : Trip-Line-Monitoring active, with response time until trip = 3 msec
<b>P07.01</b> <b>Trip-Line Level at Trip-Status</b> Range: 0 .. 1	Setting 0 : Low Level at Trip-Status (relays de-energized to Trip) 1 : High-Level at Trip-Status (relays energized to Trip)
<b>P07.02</b> <b>Signal-Input Level for Rotational Direction Detection</b> Range: 0 .. 1	Setting 0 : Signal level low is assigned to forward motion 1 : Signal level high is assigned to forward motion
<b>P07.03</b> <b>Relay State for status forward motion</b> Range: 0 .. 1	Setting 0 : Relay de-energized at status forward motion 1 : Relay energized at status forward motion
<b>P07.04</b> Reserved for future application Fix value = 0	

<b>Parameter Group P08.xx of Monitor E1666</b>	
<b>Analog Output</b>	
<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<b>P08.00</b> <b>High End of Analog Output</b> Range: 00001 .. 99999	The high end defines the speed (in terms of RPM) at which the analog output delivers 20 mamps (with P08.04 = 0) (resp. 0 / 4 mamps with P08.04 = 1).
<b>P08.01</b> <b>Low End of Analog Output</b> Range: 00000 .. 99999	The low end defines the speed (in terms of RPM) at which the analog output delivers 0 resp. 4 mamps (with P08.04 = 0) (resp. 20 mamps with P08.04 = 1).
<b>P08.02</b> <b>Analog Output Zero Level</b> Range: 0 .. 1	Setting 0 : without live zero (0..20 ma) 1 : with live zero (4..20 ma)
<b>P08.03</b> <b>Output Level at Sensor Fault</b> Range: 0 .. 2	Setting 0 : no change of output 1 : output goes to 0,0 mamps 2 : output goes to > 20,8 mamps
<b>P08.04</b> <b>Direction of Analog Output</b> Range: 0 .. 1	Setting 0 : output is increasing with increasing speed (0/4 ...20 ma) 1 : output is decreasing with increasing speed (20....4/0 ma)
<b>P08.05</b> <b>Output Response at Test-speed</b> Range: 0 .. 1	Setting 0 : output follows test speed 1 : output is frozen (on last value before test starts) during test speed
<b>P08.06</b> <b>Test of Analog Output Value</b> Range: 0 .. 1	Analog output may be checked for short circuit or no load or its correct output, detected via integrated control feedback. Setting 0 : output value is not tested (mandatory with versions E1666.0xx respective E1666.1xx) 1 : value of output is tested (only possible with versions E1666.2xx) With setting 1 the analog output is rated SIL2/IEC61508.  If a fault is detected, the analog output circuit is switched to high ohmic state, event code E.3.0.2.0 (at external fault) or E.3.0.2.1 (at internal fault = monitor must be replaced) is displayed and Monitor Warning Alarm signalized.

Parameter Group P09.xx of Monitor E1666 Reserved for future application	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P09.00</b> Reserved for future application	

**Parameter Group P10.xx of Monitor E1666  
Voter 1 and Logic Output LO1**

Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings																																			
<b>P10.00</b> <b>Operation mode Voter 1</b> Range: 0 .. 5	Setting 0 : Voter inactive 1 : always active (over entire speed range) 2 : Voter only active, if n > SPV1 3 : Voter only active, if n < SPV1 4 : Voter inactive, output LO1 low, if n > SPV1 5 : Voter inactive, output LO1 high, if n > SPV1																																			
<b>P10.01</b> <b>Input Truth Level</b> Range: 0 .. 1	Setting 0 : high level at inputs is assigned to trip condition 1 : low level at inputs is assigned to trip condition																																			
<b>P10.02</b> <b>Voting Logic</b> Range: 0 .. 3	Selectable Voting Logics are: <ul style="list-style-type: none"> <li>• 1oo2 : trip is released if 1 of 2 inputs signalizes trip condition</li> <li>• 2oo2 : trip is released if 2 of 2 inputs signalize trip condition</li> <li>• 2oo3 : trip is released if 2 of 3 inputs signalize trip condition</li> <li>• 3oo3 : trip is released if 3 of 3 inputs signalize trip condition</li> </ul> Setting 0 : 1oo2 (only inputs 1 and 2 of voter 1 are monitored) 1 : 2oo2 (only inputs 1 and 2 of voter 1 are monitored) 2 : 2oo3 (all three inputs of voter 1 are monitored) 3 : 3oo3 (all three inputs of voter 1 are monitored)																																			
<b>P10.03</b> <b>Truth Time until Trip</b> Range: 0 .. 7	If the trip signal is shorter than the minimum truth time, the signal is not valid (anti bouncing filter). If the signal is longer than the maximum truth time, the signal is valid and trip is released Note: Signal truth times in between min. and max. may release trip. Maximum response time until trip-lines go to trip status is maximum truth time + 3 milliseconds. <table border="1" data-bbox="986 1200 1414 1576"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Truth time (Trip after)</th> </tr> <tr> <th>min.</th> <th>max.</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>3 msec</td> <td>6 msec</td> </tr> <tr> <td>1</td> <td>6 msec</td> <td>9 msec</td> </tr> <tr> <td>2</td> <td>12 msec</td> <td>16 msec</td> </tr> <tr> <td>3</td> <td>24 msec</td> <td>28 msec</td> </tr> <tr> <td>4</td> <td>48 msec</td> <td>52 msec</td> </tr> <tr> <td>5</td> <td>96 msec</td> <td>102 msec</td> </tr> <tr> <td>6</td> <td>192 msec</td> <td>202 msec</td> </tr> <tr> <td>7</td> <td>384 msec</td> <td>400 msec</td> </tr> <tr> <td>8</td> <td>768 msec</td> <td>800 msec</td> </tr> <tr> <td>9</td> <td>1570 msec</td> <td>1600 msec</td> </tr> </tbody> </table>	Setting	Truth time (Trip after)		min.	max.	0	3 msec	6 msec	1	6 msec	9 msec	2	12 msec	16 msec	3	24 msec	28 msec	4	48 msec	52 msec	5	96 msec	102 msec	6	192 msec	202 msec	7	384 msec	400 msec	8	768 msec	800 msec	9	1570 msec	1600 msec
Setting	Truth time (Trip after)																																			
	min.	max.																																		
0	3 msec	6 msec																																		
1	6 msec	9 msec																																		
2	12 msec	16 msec																																		
3	24 msec	28 msec																																		
4	48 msec	52 msec																																		
5	96 msec	102 msec																																		
6	192 msec	202 msec																																		
7	384 msec	400 msec																																		
8	768 msec	800 msec																																		
9	1570 msec	1600 msec																																		
<b>P10.04</b> <b>Trip by Voter 1 latched</b> Range: 0 .. 1	Setting 0 : trip by voter 1 is not latched 1 : trip by voter 1 is latched until reset																																			



**Parameter Group P10.xx (continued) of Monitor E1666  
Voter 1 and Logic Output LO1**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<p><b>P10.05</b>  <b>Delay of Antivalence Alarm</b>                      Range: 0 .. 9</p>	<p>To avoid unnecessary Antivalence Alarms due to shifted trip release signals at the voter inputs a delay may be introduced. Antivalence alarm will then be released only if the time shift between the signals exceeds the set delay.</p> <p>Setting</p> <ul style="list-style-type: none"> <li>0 : no delay</li> <li>1 : delay = 100 milliseconds</li> <li>2 : delay = 500 milliseconds</li> <li>3 : delay = 1 second</li> <li>4 : delay = 2 seconds</li> <li>5 : delay = 3 seconds</li> <li>6 : delay = 5 seconds</li> <li>7 : delay = 15 seconds</li> <li>8 : delay = 30 seconds</li> <li>9 : delay = 60 seconds</li> </ul> <p>Note:                      The input signals will be monitored for antivalence only, if the voter is active.</p>
<p><b>P10.06</b>  <b>Setpoint SPV1</b>                      Range: 00000 .. 99999</p>	<p>Depending on setting of P10.00, SPV1 controls the activity of voter 1 or controls directly the output LO1.                      SPV1 is set in terms of RPM.</p>

**Parameter Group P11.xx of Monitor E1666  
Voter 2 and Logic Output LO2**

Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings																																			
<b>P11.00</b> <b>Operation mode Voter 2</b> Range: 0 .. 5	Setting 0 : Voter inactive 1 : Voter always active (over entire speed range) 2 : Voter only active, if n > SPV2 3 : Voter only active, if n < SPV2 4 : Voter inactive, output LO2 low, if n > SPV2 5 : Voter inactive, output LO2 high, if n > SPV2																																			
<b>P11.01</b> <b>Input Truth Level</b> Range: 0 .. 1	Setting 0 : high level at inputs is assigned to trip condition 1 : low level at inputs is assigned to trip condition																																			
<b>P11.02</b> <b>Voting Logic</b> Range: 0 .. 3	Selectable Voting Logics are: <ul style="list-style-type: none"> <li>• 1oo2 : trip is released if 1 of 2 inputs signalizes trip condition</li> <li>• 2oo2 : trip is released if 2 of 2 inputs signalize trip condition</li> <li>• 2oo3 : trip is released if 2 of 3 inputs signalize trip condition</li> <li>• 3oo3 : trip is released if 3 of 3 inputs signalize trip condition</li> </ul> Setting 0 : 1oo2 (only inputs 1 and 2 of voter 2 are monitored) 1 : 2oo2 (only inputs 1 and 2 of voter 2 are monitored) 2 : 2oo3 (all three inputs of voter 2 are monitored) 3 : 3oo3 (all three inputs of voter 2 are monitored)																																			
<b>P11.03</b> <b>Truth Time until Trip</b> Range: 0 .. 7	If the trip signal is shorter than the minimum truth time, the signal is not valid (anti bouncing filter). If the signal is longer than the maximum truth time, the signal is valid and trip is released Note: Signal truth times in between min. and max. may release trip. Maximum response time until trip-lines go to trip status is maximum truth time + 3 milliseconds. <table border="1" data-bbox="986 1200 1410 1576"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Truth time (Trip after)</th> </tr> <tr> <th>min.</th> <th>max.</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>3 msec</td> <td>6 msec</td> </tr> <tr> <td>1</td> <td>6 msec</td> <td>9 msec</td> </tr> <tr> <td>2</td> <td>12 msec</td> <td>16 msec</td> </tr> <tr> <td>3</td> <td>24 msec</td> <td>28 msec</td> </tr> <tr> <td>4</td> <td>48 msec</td> <td>52 msec</td> </tr> <tr> <td>5</td> <td>96 msec</td> <td>102 msec</td> </tr> <tr> <td>6</td> <td>192 msec</td> <td>202 msec</td> </tr> <tr> <td>7</td> <td>384 msec</td> <td>400 msec</td> </tr> <tr> <td>8</td> <td>768 msec</td> <td>800 msec</td> </tr> <tr> <td>9</td> <td>1570 msec</td> <td>1600 msec</td> </tr> </tbody> </table>	Setting	Truth time (Trip after)		min.	max.	0	3 msec	6 msec	1	6 msec	9 msec	2	12 msec	16 msec	3	24 msec	28 msec	4	48 msec	52 msec	5	96 msec	102 msec	6	192 msec	202 msec	7	384 msec	400 msec	8	768 msec	800 msec	9	1570 msec	1600 msec
Setting	Truth time (Trip after)																																			
	min.	max.																																		
0	3 msec	6 msec																																		
1	6 msec	9 msec																																		
2	12 msec	16 msec																																		
3	24 msec	28 msec																																		
4	48 msec	52 msec																																		
5	96 msec	102 msec																																		
6	192 msec	202 msec																																		
7	384 msec	400 msec																																		
8	768 msec	800 msec																																		
9	1570 msec	1600 msec																																		
<b>P11.04</b> <b>Trip by Voter 2 latched</b> Range: 0 .. 1	Setting 0 : trip by voter 2 is not latched 1 : trip by voter 2 is latched until reset																																			

**Parameter Group P11.xx (continued) of Monitor E1666  
Voter 2 and Logic Output LO2**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<p><b>P11.05</b>  <b>Delay of Antivalence Alarm</b>                      Range: 0 .. 9</p>	<p>To avoid unnecessary Antivalence Alarms due to shifted trip release signals at the voter inputs a delay may be introduced. Antivalence alarm will then be released only if the time shift between the signals exceeds the set delay.</p> <p>Setting</p> <ul style="list-style-type: none"> <li>0 : no delay</li> <li>1 : delay = 100 milliseconds</li> <li>2 : delay = 500 milliseconds</li> <li>3 : delay = 1 second</li> <li>4 : delay = 2 seconds</li> <li>5 : delay = 3 seconds</li> <li>6 : delay = 5 seconds</li> <li>7 : delay = 15 seconds</li> <li>8 : delay = 30 seconds</li> <li>9 : delay = 60 seconds</li> </ul> <p>Note:                      The input signals will be monitored for antivalence only, if the voter is active.</p>
<p><b>P11.06</b>  <b>Setpoint SPV2</b>                      Range: 00001 .. 99999</p>	<p>Depending on setting of P11.00, SPV2 controls the activity of voter 2 or controls directly the output LO2. SPV2 is set in terms of RPM.</p>

**Parameter Group P12.xx of Monitor E1666  
Voter 3 and Logic Output LO3**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>																																			
<b>P12.00</b> <b>Operation mode Voter 3</b> Range: 0 .. 5	Setting 0 : Voter inactive 1 : Voter always active (over entire speed range) 2 : Voter only active, if n > SPV3 3 : Voter only active, if n < SPV3 4 : Voter inactive, output LO3 low, if n > SPV3 5 : Voter inactive, output LO3 high, if n > SPV3																																			
<b>P12.01</b> <b>Input Truth Level</b> Range: 0 .. 1	Setting 0 : high level at inputs is assigned to trip condition 1 : low level at inputs is assigned to trip condition																																			
<b>P12.02</b> <b>Voting Logic</b> Range: 0 .. 3	Selectable Voting Logics are: <ul style="list-style-type: none"> <li>• 1oo2 : trip is released if 1 of 2 inputs signalizes trip condition</li> <li>• 2oo2 : trip is released if 2 of 2 inputs signalize trip condition</li> <li>• 2oo3 : trip is released if 2 of 3 inputs signalize trip condition</li> <li>• 3oo3 : trip is released if 3 of 3 inputs signalize trip condition</li> </ul> Setting 0 : 1oo2 (only inputs 1 and 2 of voter 3 are monitored) 1 : 2oo2 (only inputs 1 and 2 of voter 3 are monitored) 2 : 2oo3 (all three inputs of voter 3 are monitored) 3 : 3oo3 (all three inputs of voter 3 are monitored)																																			
<b>P12.03</b> <b>Truth Time until Trip</b> Range: 0 .. 7	If the trip signal is shorter than the minimum truth time, the signal is not valid (anti bouncing filter). If the signal is longer than the maximum truth time, the signal is valid and trip is released Note: Signal truth times in between min. and max. may release trip. Maximum response time until trip-lines go to trip status is maximum truth time + 3 milliseconds. <table border="1" data-bbox="986 1200 1410 1576"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Truth time (Trip after)</th> </tr> <tr> <th>min.</th> <th>max.</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>3 msec</td> <td>6 msec</td> </tr> <tr> <td>1</td> <td>6 msec</td> <td>9 msec</td> </tr> <tr> <td>2</td> <td>12 msec</td> <td>16 msec</td> </tr> <tr> <td>3</td> <td>24 msec</td> <td>28 msec</td> </tr> <tr> <td>4</td> <td>48 msec</td> <td>52 msec</td> </tr> <tr> <td>5</td> <td>96 msec</td> <td>102 msec</td> </tr> <tr> <td>6</td> <td>192 msec</td> <td>202 msec</td> </tr> <tr> <td>7</td> <td>384 msec</td> <td>400 msec</td> </tr> <tr> <td>8</td> <td>768 msec</td> <td>800 msec</td> </tr> <tr> <td>9</td> <td>1570 msec</td> <td>1600 msec</td> </tr> </tbody> </table>	Setting	Truth time (Trip after)		min.	max.	0	3 msec	6 msec	1	6 msec	9 msec	2	12 msec	16 msec	3	24 msec	28 msec	4	48 msec	52 msec	5	96 msec	102 msec	6	192 msec	202 msec	7	384 msec	400 msec	8	768 msec	800 msec	9	1570 msec	1600 msec
Setting	Truth time (Trip after)																																			
	min.	max.																																		
0	3 msec	6 msec																																		
1	6 msec	9 msec																																		
2	12 msec	16 msec																																		
3	24 msec	28 msec																																		
4	48 msec	52 msec																																		
5	96 msec	102 msec																																		
6	192 msec	202 msec																																		
7	384 msec	400 msec																																		
8	768 msec	800 msec																																		
9	1570 msec	1600 msec																																		
<b>P12.04</b> <b>Trip by Voter3 latched</b> Range: 0 .. 1	Setting 0 : trip by voter 3 is not latched 1 : trip by voter 3 is latched until reset																																			

**Parameter Group P12.xx (continued) of Monitor E1666  
Voter 3 and Logic Output LO3**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<p><b>P12.05</b>  <b>Delay of Antivalence Alarm</b>                      Range: 0 .. 9</p>	<p>To avoid unnecessary Antivalence Alarms due to shifted trip release signals at the voter inputs a delay may be introduced. Antivalence alarm will then be released only if the time shift between the signals exceeds the set delay.</p> <p>Setting</p> <ul style="list-style-type: none"> <li>0 : no delay</li> <li>1 : delay = 100 milliseconds</li> <li>2 : delay = 500 milliseconds</li> <li>3 : delay = 1 second</li> <li>4 : delay = 2 seconds</li> <li>5 : delay = 3 seconds</li> <li>6 : delay = 5 seconds</li> <li>7 : delay = 15 seconds</li> <li>8 : delay = 30 seconds</li> <li>9 : delay = 60 seconds</li> </ul> <p>Note:                      The input signals will be monitored for antivalence only, if the voter is active.</p>
<p><b>P12.06</b>  <b>Setpoint SPV3</b>                      Range: 00001 .. 99999</p>	<p>Depending on setting of P12.00, SPV3 controls the activity of voter 3 or controls directly the output LO3. SPV3 is set in terms of RPM.</p>

**Parameter Group P13.xx of Monitor E1666  
Voter 4 and Logic Output LO4**

Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings																																			
<b>P13.00</b> <b>Operation mode Voter 4</b> Range: 0 .. 5	Setting 0 : Voter inactive 1 : Voter always active (over entire speed range) 2 : Voter only active, if n > SPV4 3 : Voter only active, if n < SPV4 4 : Voter inactive, output LO4 low, if n > SPV4 5 : Voter inactive, output LO4 high, if n > SPV4																																			
<b>P13.01</b> <b>Input Truth Level</b> Range: 0 .. 1	Setting 0 : high level at inputs is assigned to trip condition 1 : low level at inputs is assigned to trip condition																																			
<b>P13.02</b> <b>Voting Logic</b> Range: 0 .. 3	Selectable Voting Logics are: <ul style="list-style-type: none"> <li>• 1oo2 : trip is released if 1 of 2 inputs signalizes trip condition</li> <li>• 2oo2 : trip is released if 2 of 2 inputs signalize trip condition</li> <li>• 2oo3 : trip is released if 2 of 3 inputs signalize trip condition</li> <li>• 3oo3 : trip is released if 3 of 3 inputs signalize trip condition</li> </ul> Setting 0 : 1oo2 (only inputs 1 and 2 of voter 4 are monitored) 1 : 2oo2 (only inputs 1 and 2 of voter 4 are monitored) 2 : 2oo3 (all three inputs of voter 4 are monitored) 3 : 3oo3 (all three inputs of voter 4 are monitored)																																			
<b>P13.03</b> <b>Truth Time until Trip</b> Range: 0 .. 7	If the trip signal is shorter than the minimum truth time, the signal is not valid (anti bouncing filter). If the signal is longer than the maximum truth time, the signal is valid and trip is released Note: Signal truth times in between min. and max. may release trip. Maximum response time until trip-lines go to trip status is maximum truth time + 3 milliseconds. <table border="1" data-bbox="986 1200 1414 1576"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Truth time (Trip after)</th> </tr> <tr> <th>min.</th> <th>max.</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>3 msec</td> <td>6 msec</td> </tr> <tr> <td>1</td> <td>6 msec</td> <td>9 msec</td> </tr> <tr> <td>2</td> <td>12 msec</td> <td>16 msec</td> </tr> <tr> <td>3</td> <td>24 msec</td> <td>28 msec</td> </tr> <tr> <td>4</td> <td>48 msec</td> <td>52 msec</td> </tr> <tr> <td>5</td> <td>96 msec</td> <td>102 msec</td> </tr> <tr> <td>6</td> <td>192 msec</td> <td>202 msec</td> </tr> <tr> <td>7</td> <td>384 msec</td> <td>400 msec</td> </tr> <tr> <td>8</td> <td>768 msec</td> <td>800 msec</td> </tr> <tr> <td>9</td> <td>1570 msec</td> <td>1600 msec</td> </tr> </tbody> </table>	Setting	Truth time (Trip after)		min.	max.	0	3 msec	6 msec	1	6 msec	9 msec	2	12 msec	16 msec	3	24 msec	28 msec	4	48 msec	52 msec	5	96 msec	102 msec	6	192 msec	202 msec	7	384 msec	400 msec	8	768 msec	800 msec	9	1570 msec	1600 msec
Setting	Truth time (Trip after)																																			
	min.	max.																																		
0	3 msec	6 msec																																		
1	6 msec	9 msec																																		
2	12 msec	16 msec																																		
3	24 msec	28 msec																																		
4	48 msec	52 msec																																		
5	96 msec	102 msec																																		
6	192 msec	202 msec																																		
7	384 msec	400 msec																																		
8	768 msec	800 msec																																		
9	1570 msec	1600 msec																																		
<b>P13.04</b> <b>Trip by Voter 4 latched</b> Einstellbereich: 0 .. 1	Setting 0 : trip by voter 4 is not latched 1 : trip by voter 4 is latched until reset																																			

**Parameter Group P13.xx (continued) of Monitor E1666  
Voter 4 and Logic Output LO4**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<p><b>P13.05</b>  <b>Delay of Antivalence Alarm</b>                      Range: 0 .. 9</p>	<p>To avoid unnecessary Antivalence Alarms due to shifted trip release signals at the voter inputs a delay may be introduced. Antivalence alarm will then be released only if the time shift between the signals exceeds the set delay.</p> <p>Setting</p> <ul style="list-style-type: none"> <li>0 : no delay</li> <li>1 : delay = 100 milliseconds</li> <li>2 : delay = 500 milliseconds</li> <li>3 : delay = 1 second</li> <li>4 : delay = 2 seconds</li> <li>5 : delay = 3 seconds</li> <li>6 : delay = 5 seconds</li> <li>7 : delay = 15 seconds</li> <li>8 : delay = 30 seconds</li> <li>9 : delay = 60 seconds</li> </ul> <p>Note:                      The input signals will be monitored for antivalence only, if the voter is active.</p>
<p><b>P13.06</b>  <b>Setpoint SPV4</b>                      Range: 00001 .. 99999</p>	<p>Depending on setting of P13.00, SPV4 controls the activity of voter 4 or controls directly the output LO4. SPV4 is set in terms of RPM.</p>

**Parameter Group P14.xx of Monitor E1666  
Voter 5 and Logic Output LO5**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>																																			
<b>P14.00</b> <b>Operation mode Voter 5</b> Range: 0 .. 5	Setting 0 : Voter inactive 1 : Voter always active (over entire speed range) 2 : Voter only active, if n > SPV5 3 : Voter only active, if n < SPV5 4 : Voter inactive, output LO5 low, if n > SPV5 5 : Voter inactive, output LO5 high, if n > SPV5																																			
<b>P14.01</b> <b>Input Truth Level</b> Range: 0 .. 1	Setting 0 : high level at inputs is assigned to trip condition 1 : low level at inputs is assigned to trip condition																																			
<b>P14.02</b> <b>Voting Logic</b> Range: 0 .. 3	Selectable Voting Logics are: <ul style="list-style-type: none"> <li>• 1oo2 : trip is released if 1 of 2 inputs signalizes trip condition</li> <li>• 2oo2 : trip is released if 2 of 2 inputs signalize trip condition</li> <li>• 2oo3 : trip is released if 2 of 3 inputs signalize trip condition</li> <li>• 3oo3 : trip is released if 3 of 3 inputs signalize trip condition</li> </ul> Setting 0 : 1oo2 (only inputs 1 and 2 of voter 5 are monitored) 1 : 2oo2 (only inputs 1 and 2 of voter 5 are monitored) 2 : 2oo3 (all three inputs of voter 5 are monitored) 3 : 3oo3 (all three inputs of voter 5 are monitored)																																			
<b>P14.03</b> <b>Truth Time until Trip</b> Range: 0 .. 7	If the trip signal is shorter than the minimum truth time, the signal is not valid (anti bouncing filter). If the signal is longer than the maximum truth time, the signal is valid and trip is released Note: Signal truth times in between min. and max. may release trip. Maximum response time until trip-lines go to trip status is maximum truth time + 3 milliseconds. <table border="1" data-bbox="986 1232 1412 1608"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Truth time (Trip after)</th> </tr> <tr> <th>min.</th> <th>max.</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>3 msec</td> <td>6 msec</td> </tr> <tr> <td>1</td> <td>6 msec</td> <td>9 msec</td> </tr> <tr> <td>2</td> <td>12 msec</td> <td>16 msec</td> </tr> <tr> <td>3</td> <td>24 msec</td> <td>28 msec</td> </tr> <tr> <td>4</td> <td>48 msec</td> <td>52 msec</td> </tr> <tr> <td>5</td> <td>96 msec</td> <td>102 msec</td> </tr> <tr> <td>6</td> <td>192 msec</td> <td>202 msec</td> </tr> <tr> <td>7</td> <td>384 msec</td> <td>400 msec</td> </tr> <tr> <td>8</td> <td>768 msec</td> <td>800 msec</td> </tr> <tr> <td>9</td> <td>1570 msec</td> <td>1600 msec</td> </tr> </tbody> </table>	Setting	Truth time (Trip after)		min.	max.	0	3 msec	6 msec	1	6 msec	9 msec	2	12 msec	16 msec	3	24 msec	28 msec	4	48 msec	52 msec	5	96 msec	102 msec	6	192 msec	202 msec	7	384 msec	400 msec	8	768 msec	800 msec	9	1570 msec	1600 msec
Setting	Truth time (Trip after)																																			
	min.	max.																																		
0	3 msec	6 msec																																		
1	6 msec	9 msec																																		
2	12 msec	16 msec																																		
3	24 msec	28 msec																																		
4	48 msec	52 msec																																		
5	96 msec	102 msec																																		
6	192 msec	202 msec																																		
7	384 msec	400 msec																																		
8	768 msec	800 msec																																		
9	1570 msec	1600 msec																																		
<b>P14.04</b> <b>Trip by Voter 5 latched</b> Range: 0 .. 1	Setting 0 : trip by voter 5 is not latched 1 : trip by voter 5 is latched until reset																																			



**Parameter Group P14.xx (continued) of Monitor E1666  
Voter 5 and Logic Output LO5**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<p><b>P14.05</b>  <b>Delay of Antivalence Alarm</b>                      Range: 0 .. 9</p>	<p>To avoid unnecessary Antivalence Alarms due to shifted trip release signals at the voter inputs a delay may be introduced. Antivalence alarm will then be released only if the time shift between the signals exceeds the set delay.</p> <p>Setting</p> <ul style="list-style-type: none"> <li>0 : no delay</li> <li>1 : delay = 100 milliseconds</li> <li>2 : delay = 500 milliseconds</li> <li>3 : delay = 1 second</li> <li>4 : delay = 2 seconds</li> <li>5 : delay = 3 seconds</li> <li>6 : delay = 5 seconds</li> <li>7 : delay = 15 seconds</li> <li>8 : delay = 30 seconds</li> <li>9 : delay = 60 seconds</li> </ul> <p>Note:                      The input signals will be monitored for antivalence only, if the voter is active.</p>
<p><b>P14.06</b>  <b>Setpoint SPV5</b>                      Range: 00001 .. 99999</p>	<p>Depending on setting of P14.00, SPV5 controls the activity of voter 5 or controls directly the output LO5. SPV5 is set in terms of RPM.</p>

**Parameter Group P15.xx of Monitor E1666  
Voter 6 and Logic Output LO6**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>																																			
<b>P15.00</b> <b>Operation mode Voter 6</b> Range: 0 .. 5	Setting 0 : Voter inactive 1 : Voter always active (over entire speed range) 2 : Voter only active, if n > SPV6 3 : Voter only active, if n < SPV6 4 : Voter inactive, output LO6 low, if n > SPV6 5 : Voter inactive, output LO6 high, if n > SPV6																																			
<b>P15.01</b> <b>Input Truth Level</b> Range: 0 .. 1	Setting 0 : high level at inputs is assigned to trip condition 1 : low level at inputs is assigned to trip condition																																			
<b>P15.02</b> <b>Voting Logic</b> Range: 0 .. 3	Selectable Voting Logics are: <ul style="list-style-type: none"> <li>• 1oo2 : trip is released if 1 of 2 inputs signalizes trip condition</li> <li>• 2oo2 : trip is released if 2 of 2 inputs signalize trip condition</li> <li>• 2oo3 : trip is released if 2 of 3 inputs signalize trip condition</li> <li>• 3oo3 : trip is released if 3 of 3 inputs signalize trip condition</li> </ul> Setting 0 : 1oo2 (only inputs 1 and 2 of voter 6 are monitored) 1 : 2oo2 (only inputs 1 and 2 of voter 6 are monitored) 2 : 2oo3 (all three inputs of voter 6 are monitored) 3 : 3oo3 (all three inputs of voter 6 are monitored)																																			
<b>P15.03</b> <b>Truth Time until Trip</b> Range: 0 .. 7	If the trip signal is shorter than the minimum truth time, the signal is not valid (anti bouncing filter). If the signal is longer than the maximum truth time, the signal is valid and trip is released Note: Signal truth times in between min. and max. may release trip. Maximum response time until trip-lines go to trip status is maximum truth time + 3 milliseconds. <table border="1" data-bbox="986 1198 1412 1579"> <thead> <tr> <th rowspan="2">Setting</th> <th colspan="2">Truth time (Trip after)</th> </tr> <tr> <th>min.</th> <th>max.</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>3 msec</td> <td>6 msec</td> </tr> <tr> <td>1</td> <td>6 msec</td> <td>9 msec</td> </tr> <tr> <td>2</td> <td>12 msec</td> <td>16 msec</td> </tr> <tr> <td>3</td> <td>24 msec</td> <td>28 msec</td> </tr> <tr> <td>4</td> <td>48 msec</td> <td>52 msec</td> </tr> <tr> <td>5</td> <td>96 msec</td> <td>102 msec</td> </tr> <tr> <td>6</td> <td>192 msec</td> <td>202 msec</td> </tr> <tr> <td>7</td> <td>384 msec</td> <td>400 msec</td> </tr> <tr> <td>8</td> <td>768 msec</td> <td>800 msec</td> </tr> <tr> <td>9</td> <td>1570 msec</td> <td>1600 msec</td> </tr> </tbody> </table>	Setting	Truth time (Trip after)		min.	max.	0	3 msec	6 msec	1	6 msec	9 msec	2	12 msec	16 msec	3	24 msec	28 msec	4	48 msec	52 msec	5	96 msec	102 msec	6	192 msec	202 msec	7	384 msec	400 msec	8	768 msec	800 msec	9	1570 msec	1600 msec
Setting	Truth time (Trip after)																																			
	min.	max.																																		
0	3 msec	6 msec																																		
1	6 msec	9 msec																																		
2	12 msec	16 msec																																		
3	24 msec	28 msec																																		
4	48 msec	52 msec																																		
5	96 msec	102 msec																																		
6	192 msec	202 msec																																		
7	384 msec	400 msec																																		
8	768 msec	800 msec																																		
9	1570 msec	1600 msec																																		
<b>P15.04</b> <b>Trip by Voter 6 latched</b> Range: 0 .. 1	Setting 0 : trip by voter 6 is not latched 1 : trip by voter 6 is latched until reset																																			

**Parameter Group P15.xx (continued) of Monitor E1666  
Voter 6 and Logic Output LO6**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<p><b>P15.05</b>  <b>Delay of Antivalence Alarm</b>                      Range: 0 .. 9</p>	<p>To avoid unnecessary Antivalence Alarms due to shifted trip release signals at the voter inputs a delay may be introduced. Antivalence alarm will then be released only if the time shift between the signals exceeds the set delay.</p> <p>Setting</p> <ul style="list-style-type: none"> <li>0 : no delay</li> <li>1 : delay = 100 milliseconds</li> <li>2 : delay = 500 milliseconds</li> <li>3 : delay = 1 second</li> <li>4 : delay = 2 seconds</li> <li>5 : delay = 3 seconds</li> <li>6 : delay = 5 seconds</li> <li>7 : delay = 15 seconds</li> <li>8 : delay = 30 seconds</li> <li>9 : delay = 60 seconds</li> </ul> <p>Note:                      The input signals will be monitored for antivalence only, if the voter is active.</p>
<p><b>P15.06</b>  <b>Setpoint SPV6</b>                      Range: 00001 .. 99999</p>	<p>Depending on setting of P15.00, SPV6 controls the activity of voter 6 or controls directly the output LO6. SPV6 is set in terms of RPM.</p>

<b>Parameter Group P16.xx of Monitor E1666</b> <b>Reserved for future application</b>	
<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<b>P16.00</b> Reserved for future application	
<b>P16.01</b> Reserved for future application	
<b>P16.02</b> Reserved for future application	
<b>P16.03</b> Reserved for future application	
<b>P16.04</b> Reserved for future application	
<b>P16.05</b> Reserved for future application	
<b>P16.06</b> Reserved for future application	
<b>P16.07</b> Reserved for future application	
<b>P16.08</b> Reserved for future application	

<b>Parameter Group P17.xx of Monitor E1666</b> <b>PROFIBUS</b>	
<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<b>P17.00</b> <b>Device No. for PROFIBUS</b> Range: 001 .. 125	All members of the PROFIBUS-Communication must have different device nos.
<b>P17.01</b> <b>Address Offset for second PROFIBUS Interface</b> Range: 0 .. 9	For test purposes (operation of both PROFIBUS Interfaces at the same Bus) an address offset may be introduced for the second (right one on front panel) PROFIBUS Interface. Example: With P17.00 = 34 und P17.01 = 4 the right hand side PROFIBUS Interface has address 38.

Param. No.	Default value	Parameter Function
<b>P00.xx</b>		Code figure, Parameter Lock
P00.00	0000	Code figure
.01	0000	New code figure
.02	1	Frontside Parameter Lock : 0: locked / 1: enabled
<b>P01.xx</b>		Output Scaling
P01.00	0	Reserved for future application
.01	10000	Value of output frequency in Hz at nominal Test-Speed
.02	0	Reserved for future applications
.03	10000	Nominal Test-Speed in RPM
<b>P02.xx</b>		Monitor-Test Configuration
P02.00	0	Reserved for future application
.01	0	Reserved for future application
.02	0120	Test Interval in xxxx minutes
.03	0	Test of SP1 or Test of SP1A and SP1B
.04	11000	Test-Speed 1: 'n > SP1'
.05	09000	Test-Speed 2: 'n < SP1'
<b>P03.xx</b>		Trip-Line Test Configuration
P03.00	00120	Test Interval in xxxxx minutes (max 65000)
.01	0	Test Mode: 0 ... 3 (see parameter description)
.02	0	Reserved for future application
.03	0	Feedback-Signal level at trip : 0: low / 1: high
.04	0	Reserved for future applications
.05	00	duration time for Trip-Line test in xx sec
.06	0	Reserved for future application
.07	30	Waiting time after reset of alarms in xx sec
.08	0	Waiting time after test of a Trip-Line in xx sec
.09	0	Reserved for future application
<b>P04.xx</b>		
P04.00	00	Fix value 0, do not change
<b>P05.xx</b>		PROFIBUS-Interface
P05.00	033	PROFIBUS-Interface Device no
.01	0	Address Offset for second Profibus Interface

Parameter Group P00.xx of Test-Generator E1698 Code Figure, Parameter Lock	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P00.00</b> <b>Code Figure</b> Range: 0000 .. 9999	If the parameters are locked (see P00.02), the code figure must be entered prior to any change of other parameters. If the code figure is not correct, -E 1- is displayed. Without code figure and P00.02 : 0 the values of all parameters may be inspected, but not changed.
<b>P00.01</b> <b>New Code Figure</b> Range: 0000 .. 9999	A new code figure may be set in P00.01. Then it replaces the previous one.
<b>P00.02</b> <b>Frontside Parameter Lock</b> Range: 0 .. 1	Setting 0 : Parameters are locked, change only possible with code figure 1 : Parameters unlocked, change of parameter values possible



Parameter Group P02.xx of Test-Generator E1698 Monitor Test	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P02.00</b> Reserved for future application	
<b>P02.01</b> Reserved for future application	
<b>P02.02</b> <b>Time Interval in between Monitor Test Sequences</b> Range: 0001 .. 9999 [min]	The time interval in between the Monitor Test sequences can be set from 0001 to 9999 minutes. Recommended settings: any time in between 60 and 1440 minutes.
<b>P02.03</b> <b>Test of SP1</b> or <b>Test of SP1A and SP1B</b> Range: 0 .. 3	De-Energize/Energize depends on the setting of P03.02 of monitors E1666. Setting 0 : if test of SP1 only is required 1 : not permissible 2 : not permissible 3 : if test of SP1A and SP1B is required  <b>Explanation:</b> If P02.03 = 0 or 2, then Test-Speed 1 and 2: In the first step of the monitor auto test sequence, the monitor is tested with test-speed 1. Value for test-speed 1 must be > SP1 of monitor. In the second step of the monitor auto test sequence, the monitor is tested with test-speed 2. Value for test-speed 2 must be < SP1 of monitor.  <b>Example:</b> SP1 of monitor is set to 3300 RPM. Recommended value for Test-speed 1 : 3305 RPM Recommended value for Test-speed 2 : 3295 RPM  If P02.03 = 3, then P02.04 must be set to SP1A (P03.00 of E1666) and P02.05 must be set to SP1B (P03.03 of E1666). Test will then be performed with Test-Speed SP1A +/- 5RPM and with Test-Speed SP1B +/- 5RPM.



**Parameter Group P02.xx (continued) of Test-Generator E1698  
Monitor Test**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<b>P02.04</b> <b>Test-Speed 1 resp. SP1A</b> Range: 00001 .. 99999 [RPM]	See explanation of step P03.02
<b>P02.05</b> <b>Test-Speed 2 resp. SP1B</b> Range: 00001 .. 99999 [RPM]	See explanation of step P03.02

**Parameter Group P03.xx of Test-Generator E1698**  
**Trip-Line Test**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<b>P03.00</b> <b>Time Interval in between Trip-Line Test Sequences</b> Range: 00001 .. 65000 [min]	The time interval in between automatic (see P03.01) Trip-Line Test sequences can be set from 00001 to 65000 minutes. Recommended settings: not less than 60 minutes.
<b>P03.01</b> <b>Trip-Line Test Mode</b> Range: 0 .. 6	Setting 0 : Trip-Line Test off, feedback signal from 2oo3 solenoid valve block are not evaluated) 1 : Trip-Line Test sequence in automatic mode (cyclic, interval as set in P03.00); feedback signals from 2oo3 solenoid valve block will be evaluated. If the feedback does not signalize trip status, the output will hold the corresponding Trip-Line on trip status and the test is aborted. 2 : Trip-Line Test controlled by external signals, simultaneous test of 2 or 3 lines is inhibited, feedback signals from 2oo3 solenoid valve block are not evaluated 3 : one single Trip-Line Test Sequence, externally triggered by signal Start Auto-Test-Sequence; feedback signals from 2oo3 solenoid valve block will be evaluated, 4 : Trip-Line Test controlled by external signals, simultaneous test of 2 or 3 lines is possible, feedback signal from Valve Control Circuits are not evaluated. 5 : Trip-Line Test sequence in automatic mode (cyclic, interval as set in P03.00); feedback signals from 2oo3 solenoid valve block will be evaluated. If the feedback does not signalize trip status, the output will return to No Trip status and the test is aborted. 6 : Reserved for future application
<b>P03.02</b> Reserved for future application	
<b>P03.03</b> <b>Feedback Level from 2oo3 solenoid valve block at trip state</b> Range: 0 .. 1	Setting 0 : low level feedback expected at trip state 1 : high level feedback expected at trip state
<b>P03.04</b> Fix value 0, do not change	

**Parameter Group (continued) P03.xx of Test-Generator E1698**  
**Trip-Line Test**

<b>Parameter No.</b> <b>Meaning of Parameter</b> Setting Range of Parameter	<b>Description of Parameters and their Settings</b>
<b>P03.05</b> <b>Duration of Trip-Line Test</b> Range: 00 .. 99 [s]	If automatic sequence is activated (P03.01 = 1 or = 3), each Trip-Line is set (subsequently) to trip condition for the duration set in P03.05. Duration is set in terms of seconds. <b>Note:</b> Setting 00 sets the Trip-Line to trip condition for 0.5 seconds.
<b>P03.06</b> Reserved for future application	
<b>P03.07</b> <b>Waiting Time after Reset of Alarms</b> Range: 00 .. 99 [s]	After a reset of an alarm, the Test-Generator waits for this time before it starts to check the external feedback signals. Waiting time is set in terms of seconds. <b>Note:</b> Setting 00 equals 01.
<b>P03.08</b> <b>Waiting Time after test of a Trip-Line</b> Range: 00 .. 99 [s]	The Test-Generator waits after the test of a Trip-Line for this time before it permanently checks again the status of the feedback signals from the Trip-Lines for No-Trip-state. Waiting time is set in terms of seconds. <b>Note:</b> Setting 00 equals 01.
<b>P03.09</b> Reserved for future application	

Parameter Group P04.xx of Testgenerator E1698 Only used for E16A358 systems	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P04.00</b> Fix value = 0, do not change	

Parameter Group P05.xx of Testgenerator E1698 PROFIBUS	
Parameter No. Meaning of Parameter Setting Range of Parameter	Description of Parameters and their Settings
<b>P05.00</b> <b>Device No. for PROFIBUS</b> Range: 001 .. 125	All members of the PROFIBUS-Communication must have different device nos.
<b>P05.01</b> <b>Address Offset for second PROFIBUS Interface</b> Range: 0 .. 9	For test purposes (operation of both PROFIBUS Interfaces at the same Bus) an address offset may be introduced for the second (right one on front panel) PROFIBUS Interface. <b>Example:</b> With P05.00 = 33 und P05.01 = 4 the right hand side PROFIBUS Interface has address 37.

## 10 Event codes and Troubleshooting

### 10.1 Event codes on display of Monitor E1666

The Event codes are shown in format E.0.x.x.x .  
Depending on setting of P02.11 only the first occurred event or all events are displayed (combination of events is possible).

Display	Explanation of Event code
E.0.0.0.0	Overspeed trip (if P03.02 = 0)
E.0.x.x.1	Sensor failure (current or voltage), refer to P02.05
E.0.x.x.2	Deviation of primary sensor versus neighbor sensors, refer to P02.07
E.0.x.x.3	E.x.x.x.1 + E.x.x.x.2
E.0.x.x.4	Speed < SP2
E.0.x.x.5	E.x.x.x.1 + E.x.x.x.4
E.0.x.x.6	E.x.x.x.2 + E.x.x.x.4
E.0.x.x.7	E.x.x.x.1 + E.x.x.x.2 + E.x.x.x.4
E.0.x.1.x	Generator tests with zero speed
E.0.0.2.x	Trip by Voter
E.0.x.4.x	Internal relay fault
E.0.1.x.x	Failure detection during internal self test
E.0.2.x.x	Overspeed trip (if P03.02 = 1)
E.0.3.x.x	E.x.1.x.x + E.x.2.x.x
E.0.4.0.0 without Trip	Alarm caused by antivalence of Voter Signals or signals for Trip-Line-Monitoring (for troubleshooting refer to next page)
E.0.4.0.0 with Trip	Trip-Line Monitoring has caused trip
E.0.4.2.0	Trip by voter (with non-coincidence at inputs of voter)
E.0.6.x.x	E.x.2.x.x + E.x.4.x.x
E.0.8.0.0	Trip-Line Monitoring has caused trip plus antivalence of signals for Trip-Line-Monitoring (for troubleshooting refer to next page)
E.0.A.0.0	Trip due to overspeed (and P07.00 = 1 or 3)
E.0.c.0.0	Trip-Line Monit by antivalence of signals for Trip-Line-Monitoring (for troubleshooting refer to next page)
E.3.0.1.0	Starter active at speed > 50% of value of SP1A (only if P02.06 = 1 or 2)
E.3.0.2.0	External Analog output error (short circuit / 'no load' detected via feedback from monitor terminals)
E.3.0.2.1	Internal Analog output error (fault on monitor board)
E.3.1.0.0	Value of SP1B larger than SP1A, if P03.04 = 1 : not permissible
-E1-	Wrong code figure in step P00.00
-E4-	No test by E1698 for more than 7 days (releases also Monitor Warning Alarm)

Display E.0.4.x.x signalizes a fault (not all signals are identical) from the input signals for the voters or for Trip-Line-Monitoring (resp. feedbacks from 2oo3-solenoid).  
The actual status of the signal inputs is shown in Special Display Mode 2.

Switching between Standard and Special Display Mode 2 by pressing keys  $\square$  and  $\square$  simultaneously.

In Special Display Mode 2 LED1 and LED4 are blinking.

Steps of Special Display Mode 2:

- 0.\_x.x.x
- 1.\_x.x.x
- 2.\_x.x.x
- 3.\_x.x.x
- 4.\_x.x.x

Steps of Special Display Mode 2 are selected with key  $\square$  (next step) resp. key  $\square$  (previous step).

For troubleshooting only steps 3.\_x.x.x and 4.\_x.x.x are relevant.

The status of signal inputs for Trip-Line-Monitoring are shown in step 3.

Display of:

- 3.\_x.x.1 : Feedback signal from Trip-Line I is true
- 3.\_x.x.2 : Feedback signal from Trip-Line II is true
- 3.\_x.x.4 : Feedback signal from Trip-Line III is true

resp. all combinations hereof, for example:

- 3.\_x.x.7 : all Feedback signal from Trip-Lines are true

The voter signal inputs are shown in step 4.\_x.x.x

Display of:

- 4.n.0.0.1 : Voter n, input 1 active n = 1 - 6 (7 reserved)
- 4.n.0.0.2 : Voter n, input 2 active
- 4.n.0.0.4 : Voter n, input 3 active

resp. all combinations hereof, for example:

- 4.3.0.0.5 : Voter 3, inputs 1 und 3 active, input 2 not active

While key  $\square$  is pressed, the input status latched at error will be shown, else the current input status.

Switch the input status of voter 1 to 6 with key  $\square$  .

### 10.3 Event codes on display of Testgenerator E1698

Display	Explanation of Event code
C0-E1	Trip status notification from Monitor A
C0-E2	Trip status notification from Monitor B
C0-E3	Trip status notification from Monitor A + B
C0-E4	Trip status notification from Monitor C
C0-E5	Trip status notification from Monitor A + C
C0-E6	Trip status notification from Monitor B + C
C0-E7	Trip status notification from Monitor A + B + C
C1-E1	Fault during Test of Monitor A at step 1
C1-E2	Fault during Test of Monitor A at step 2
C1-E3	Fault during Test of Monitor A at step 3
C2-E1	Fault during Test of Monitor B at step 1
C2-E2	Fault during Test of Monitor B at step 2
C2-E3	Fault during Test of Monitor B at step 3
C3-E1	Fault during Test of Monitor C at step 1
C3-E2	Fault during Test of Monitor C at step 2
C3-E3	Fault during Test of Monitor C at step 3
C9-E1	Fault of Monitor A subsequent to a test step
C9-E2	Fault of Monitor B subsequent to a test step
C9-E4	Fault of Monitor C subsequent to a test step
C9-E7	All Monitors on Trip at start of test
ECh0.1	Alarm notification from Monitor A
ECh0.2	Alarm notification from Monitor B
ECh0.3	Alarm notification from Monitor A + B
ECh0.4	Alarm notification from Monitor C
ECh0.5	Alarm notification from Monitor A + C
ECh0.6	Alarm notification from Monitor B + C
ECh0.7	Alarm notification from Monitor A + B + C

**Event codes on display of E1698 (continued)**

<b>Display</b>	<b>Explanation of Event code</b>	<b>(y = not relevant with this code)</b>
E.0.y.y.1	Trip-Line I in Trip-Status	
E.0.y.y.2	Trip-Line II in Trip-Status	
E.0.y.y.4	Trip-Line III in Trip-Status	
E.0.y.y.7	Trip-Lines I, II, III in Trip-Status	
E.1.y.y.0	Incorrect feedback from Trip-Line I at test of Trip-Line I	
E.1.y.y.2	Incorrect feedback from Trip-Line II at test of Trip-Line I	
E.1.y.y.4	Incorrect feedback from Trip-Line III at test of Trip-Line I	
E.2.y.y.0	Incorrect feedback from Trip-Line II at test of Trip-Line II	
E.2.y.y.4	Incorrect feedback from Trip-Line III at test of Trip-Line II	
E.3.y.y.0	Incorrect feedback from Trip-Line III at test of Trip-Line III	
FC-5.1	Test outputs are asynchronous: if code reappears subsequent to reset, one of the test outputs has a hardware fault and E1698 must be replaced	
FC-5.2	Input Test Lock is active	
FC-5.6	Input Test Lock is active for more than 10 minutes	



Date	Rev.	Änderung
16.12.2016	00	Initial release